

DM16-03.01.46en



INSTALLATION & OPERATION AND MAINTENANCE MANUAL

Air-cooled Screw Chiller Unit

Applicable Model:

MLSC380A-SB3Z/MRH380A-B3Z

MLSC500A-SB3Z/MRH500A-B3Z

MLSC600A-SB3Z/MRH600A-B3Z

Please Keep This Manual Carefully For Future Reference

Notice

- The installation section of this manual is designed for qualified persons only.
- Be sure to read the operating section before conducting operation in order to prevent unit damage and unnecessary accidents.
- The contents of this manual are subject to change without prior notice for further improvement of related models.
- The product introduced in this manual is in compliance with GB/T18430.1-2007.
- Report to and register in the local corresponding administrative organization before and after operating the pressure vessel unit.
- The air source screw water chiller unit is designed based on the following conditions:

	Refrigeration Condition
Water side outlet temperature	5℃-15℃
Air side inlet temperature	10℃-43℃



Personnel must be fully acquainted with the operation manual before operating the refrigerant system.

Safety Warning

The MLSC A series units adopt the R134a refrigerant, which is the mid-pressure medium and liquefied gas. The saturated vapor pressure of R134a refrigerant corresponds to the temperature. That is, if the temperature is high and the corresponding saturated vapor pressure is high too. To ensure the safety of units, the ambient temperature cannot be higher than 43℃ during the downtime of units. Otherwise, you should start the chilled water pump to decrease the temperature of the evaporator. When the unit is charged with refrigerant, it is forbidden to perform flame-cut or welding operations on the shell and tube heat exchanger, finned heat exchanger, reservoir, and unit pipes. When the unit operates or bears the pressure, it is forbidden to fasten bolt or nut. If contact surfaces leak, you can fasten the bolt and nut only after the pressure is released. Avoid refrigerant leakage in case of unit debugging and usage. The R134a vapor concentration (AEL) in the air that human body can accept is 1000 ppm. It has no adverse impact on human body within the specified vapor concentration. R134a vapors are concentrated near the low ground when large spills or leakages occur, which may cause hypoxia and make you feel uncomfortable. In this case, improve ventilation or blast air by using fan coil to keep the air near the ground in circulation. Do not enter the polluted area until the refrigerant vapor is discharged, avoiding the adverse impact. The liquid refrigerant cannot be contacted with skin and eyes to avoid frostbite.

Pay more attention to the following conditions to ensure safety when using this series of units in closed areas:

- Install outlet pipes and ventilating pipes outdoors and keep away from the air inlet.
- Keep sufficient ventilation and use auxiliary ventilating devices to remove refrigerant vapor leaked accidentally if necessary.
- If applicable, connect the outlet of safety valve to the outdoors by using pipes.
- If applicable, install the air detector to monitor the refrigerant vapor concentration in the air.

Other precautions:

- Be sure to read and strictly comply with safety requirements.
- Please keep this manual carefully for future reference and read it carefully before operation.
- Ensure that controllers are properly connected to the ground and frequently check whether it is stable, because poor earthing may result in electric shock.
- Please abide by the principle of electricity separation.
- Please install the unit according to the wiring diagram.Do not use sharp objects to press the touch screen or put excess stress on the touch screen, avoiding touch screen

damage.

- Do not drag and distort power cables and communication lines, avoiding major failure.
- Please wring the cloth dampened with neutral water, and wipe the unit to remove fouling.
 Do not use acidic, alkaline chemicals.
- If fire breaks out accidentally, you should immediately shut down the main power and use fire extinguisher applicable to oil fire and electric fire.
- The units cannot be used in explosive environment.
- Please contact the manufacturer if you need to repair the unit. Do not repair it by yourself.

Contents

1 Introduction	1
1.1 Function	1
1.2 Features	1
1.3 Product Components	2
2 Model, Specifications, and Application Range	7
2.1 Specifications	7
2.2 Application Range	10
3. Evaporator Pressure Drop Curve	10
4. Accessories and Models with Special Features	11
4.1 Standard Accessories	11
4.2 Optional Accessories	11
4.3 Models with Special Features	11
5 Operating Principle	
6 Installation	
6.1 Loading/Unloading and Hoisting (Diagram)	13
6.2 Requirements for Foundation Installation and Diagrams of Foundation	on15
6.3 Installation Space and Appearance	19
C 4 De suite se suite fan Mister Oustern hestelletien en di Deserveren de di Die	aram for the Water
6.4 Requirements for Water System Installation and Recommended Dia	grann for the water
6.4 Requirements for Water System Installation and Recommended Dia System	
6.5 Electrical Installation	45
 6.4 Requirements for Water System Installation and Recommended Dia System	45 48
 6.4 Requirements for Water System Installation and Recommended Dia System	45 45
 6.4 Requirements for Water System Installation and Recommended Dia System 6.5 Electrical Installation	45 45
 6.4 Requirements for Water System Installation and Recommended Dia System	45 45
 6.4 Requirements for Water System Installation and Recommended Dia System	
 6.4 Requirements for Water System Installation and Recommended Dia System	
 6.4 Requirements for Water System Installation and Recommended Dia System	
 6.4 Requirements for Water System Installation and Recommended Dia System 6.5 Electrical Installation 7 Commissioning 7.1 Check Before Commissioning 7.2 Commissioning Operations 8 Daily Use of the Unit 8.1 Check Before Use 8.2 Unit Startup Sequence 8.3 Unit Stop Sequence 8.4 Control Interface Structure 	
 6.4 Requirements for Water System Installation and Recommended Dia System	
 6.4 Requirements for Water System Installation and Recommended Dia System 6.5 Electrical Installation 7 Commissioning 7.1 Check Before Commissioning 7.2 Commissioning Operations 8 Daily Use of the Unit 8.1 Check Before Use 8.2 Unit Startup Sequence 8.3 Unit Stop Sequence 8.4 Control Interface Structure 8.5 Operation 8.6 Fault Alarm Function 	grain for the water 45 48 66 67 67 69 69 69 69 69 69 69
 6.4 Requirements for Water System Installation and Recommended Dia System	grain for the water 45 48 66 67 67 69 69 69 69 69 69
 6.4 Requirements for Water System Installation and Recommended Dia System 6.5 Electrical Installation 7 Commissioning 7.1 Check Before Commissioning. 7.2 Commissioning Operations. 8 Daily Use of the Unit. 8.1 Check Before Use. 8.2 Unit Startup Sequence. 8.3 Unit Stop Sequence . 8.4 Control Interface Structure 8.5 Operation. 8.6 Fault Alarm Function. 8.7 Safety Protection Flowchart. 8.8 Precautions for Unit Operation. 	grain for the water 45 48 66 66 67 69 69 69 69 69 69
 6.4 Requirements for Water System Installation and Recommended Dia System	
 6.4 Requirements for Water System Installation and Recommended Dia System	grain for the water 45 48 66 67 69 69 69 69 69 69 69

10.2 Cleaning the Shell-and-Tube Heat Exchanger	106
10.3 Procedure for Replacing the Dry FilterElement	
10.4 Lubricant	
10.5 Charging and Evacuating Refrigerants	
10.6 Routine Maintenance Items	
10.7 Safety Requirements for Maintaining the Water Chiller Unit	111

1 Introduction

1.1 Function

The air source screw water chiller unit has been forging ahead at the forefront of air-cooled unit. It saves various auxiliary parts such as cooling tower, cooling pump, and corresponding pipe systems. Featuring simple system structure, it saves installation space. In addition, it saves energy and can be maintained and managed conveniently. Therefore, it is especially suitable for the area lack of water. The indoor unit of air source screw water chiller unit adopts the semi-closed twin-screw compressor with advanced technology, low noise, and high efficiency. The twin-screw compressor can deliver the optimal performance when it is used with the evaporator and condenser that are efficient in heat exchange. The outdoor unit adopts refrigerating pipes design and free of anti-freezing fluid. Condenser fins with high effective and low noise fan are placed on the condensing pipes based on a certain gap. The unit framework adopts steel structure with anticorrosive paint on the surface to ensure the reliability and performance during unit operation.

The air source screw water chiller unit is transported to the site in split mode. The refrigerant pipes of indoor units have been properly assembled before delivery, and charged with the necessary refrigerants and lubricants. The air source screw water chiller unit adopts twin-screw compressor designed with the most advanced, industrial third-generation asymmetric technology of 5 gear teeth to 6 gear teeth. The detailed functions are as follows:

- Variable capacity adjustment, high efficiency, and energy saving.
- Human-orientated micro-computer control system with remote control function.
- Ten self-protection functions to ensure the safe and reliable operation.

This full series of units have diversified models and can be customized for you.

The company adheres to the customer-driven design concept to meet customer's various requirements.

This series of units features compact structure, small size, low noise, high COP, long service life, easy operation and maintenance, and other advantages. Therefore, they are widely used in multiple scenarios such as hotels, restaurant, office buildings, shopping malls, hospitals, etc. In addition, they are applicable to air conditioning scenarios such as metallurgical, chemical, mechanical and electronic industry.

1.2 Features

1.2.1 Simple and Economic Apparatus

- (1) The compact appearance makes this series of units widely used for various buildings, saving the space for the equipment room.
- (2) The bolt joints allow you to rapidly and conveniently assemble and disassemble the units.
- (3) Lightweight design simplifies the operation requirements and reduces installation time and cost.
- (4) Units have been charged with refrigerants and lubricants before delivery, which reduces the onsite

workload, material, and installation cost.

- (5) Customers only need to connect the refrigerant pipes, evaporator water pipes, and power cables between outdoor units and indoor units to use the units, simplifying the entire installation process.
- (6) The split design of units is free of larger installation base, and removes the oil cooler and related purification systems, reducing the unit weight. In addition, outdoor units can be installed far away from the master unit, reducing operation noise.
- (7) The unit is tested under various conditions before its delivery.
- (8) The unit is directly driven. In addition, it operates in a high efficient and reliable way with fewer movable components. Therefore, it can be easily maintained and serviced.
- (9) The unit is easily installed without requiring a cooling tower. It releases heat to the air when it is in cooling mode without requiring a cooling tower and cooling pump. Therefore, it is especially suitable for water-deficient areas. The indoor unit requires a dedicated equipment room. The outdoor unit can be installed on the rooftop, ground and other outdoor places.

1.2.2 Technical State and Precise Control

- The unit is fitted with sensors and other components related to control before delivery, and it has been tested.
- (2) Smart control: Adopts micro-computer controller featuring various automatic control functions such as fault diagnosis, and energy management and monitoring, which ensures efficient running and easy operation of the unit. The unit provides the RS485 communication interface, which allows the host computer to control startup/stop of the unit, minimizing the operation cost.
- (3) Complete safety control system: Electrical control elements are of world well-known brands with stable quality and reliable performance. In addition, units are designed with multiple safety protections including high/low pressure, oil differential pressure, antifreeze, water flow volume, anti-phase, and overload, which ensures safe and reliable operation of the unit.

1.2.3 Reliability and Ease Maintenance

- (1) The unit is directly driven with a low rev and ease maintenance. In addition, it operates in high efficient and reliable way with less movable components.
- (2) The unit is in stable performance by using the electronic expansion valve technology.

1.2.4 Easy Installation and Simple Structure

The unit has been subject to comprehensive commissioning before delivery, ensuring the reliability of the unit's onsite operation. For onsite installations, you just need to connect the unit to the supply power, refrigerant pipe, and water source. Then the unit starts to work after simple installation and debugging. Additionally, the unit is easy to operate and fitted with automatic protection and adjustment apparatus, which facilitates the management.

1.3 Product Components



1.3.1 Compressor



- (1) The unit adopts twin-screw compressor designed with the most advanced, industrial third-generation asymmetric technology of 5 gear teeth to 6 gear teeth. The screw rotor is a patented product based on effective improvement of the German GHH rotor profile. The male and female rotors are designed by using CNC high-precision screw rotor processing equipment, which allows each component to evenly distribute and work in gapless. This minimizes the frictional resistance and ensures the low sound operation and long service life. Compared with single screw compressor, the twin-screw compressor features gapless loss, efficiency in capacity, low noise, and fewer quick-wear parts, which has got the British and American patents.
- (2) The differential pressure fuel helps optimize the performance of each movable component in the compressor to achieve the optimal lubrication result without extra oil pump. This saves the complex oil system and makes the entire system simple. Therefore, the maintenance is more convenient and operation is more reliable.
- (3) The special high-precision zero clearance bearing ensures the long service life of units.
- (4) The SKF compressor bearing from Sweden with long service life is used, ensuring that the screw master units can continuously work more than 30,000 hours for a long term.

1.3.2 Evaporator

Shell-and-tube evaporator adopts high-efficiency heat transfer tubes and special tube layout design. It fully considers the state change, the flow velocity, the pressure drop of the refrigerant in refrigerant condition to ensure sufficient evaporation and strengthen the refrigerating capacity.

1.3.3 Condenser

Copper-fin heat exchanger adopts high- efficiency heat transfer tubes with the feature of high efficiency and so on. The unit is able to adjust the capacity matching with load change to improve the efficiency of compressor, reduce the energy consumption, and increase the unit's service life.

Fans featuring low noise, stable operation, and slight shaking are installed on the top of condensers, generating low noise and high power.

Aluminous-fin cupreous corrosion resistant tubes are cross banding to supply high coefficient of heat transfer.

1.3.4 Safety Valve

Midea

The safety value of units helps release the dangerous high pressure. To avoid device damage and personal injury, these apparatuses must work in the optimal status.

Therefore, it is necessary to perform the following maintenance tasks:

- (1) Disassemble the eduction pipe of the outlet value at least once a year to check whether corrosion, rust, dust, scale deposit, and leakage are found inside the value.
- (2) Replace the safety valve instead of repairing it, if corrosion and foreign matter are found.
- (3) Check the valve more frequently if the unit is installed in corrosive environment or the safety valve discharges air into corrosive environment.

1.3.5 Economizer

For units with economizer, the cooling capacity and efficiency will be improved through the cooling circulation or two-step cooling circulation. The energy saving effect is noticeable especially at high condensing temperature and low evaporation temperature. The unique economizer access port of screw compressor directly takes the gaseous liquid back to the compressor in the optimum compression ratio for recompression.

1.3.6 Liquid Injection System

The two-step liquid injection system avoids the superheat in case of compressor overload. In addition, the flexible control mode reduces the impact on the energy efficiency of units.

1.3.7 Smart Control

- (1) The unit adopts micro-computer controller featuring various automatic control functions such as fault diagnosis, energy management, and antifreeze monitoring, which ensures efficient running and easy operation of the unit. The unit features built-in RS485 communication interface, and multiple units can be controlled through interconnection. With the RS485/RS232 switching interface program, the unit can be controlled by the host computer. The host computer controls the startup/stop of units based on the load requirement and operating time.
- (2) Multiple self-protections ensure the unit's safe and reliable operation.

1.3.8 Variable Capacity Adjustment, High Efficiency, and Energy Saving

The high-precision capacity control valve traces the unit's load changes and adjusts the refrigerant volume. The capacity adjustment can adopt four-step control mode (25%, 50%, 75%, and 100%) or stepless adjustment (this function must be noted on the order), which saves operating cost for customers.



Capacity adjustment curve



Capacity adjustment diagram for compressor

2 Model, Specifications, and Application Range

2.1 Specifications

2.1.1 Nominal Cooling Capacities

Indoor Unit

Model			MLSC380A-SB3Z MLSC500A-SB3Z MLSC600A-SB3Z				
Cooling capa	acity	kW	380	496	594		
Cooling input power kW		kW	124	159	187		
Type			Semi-hermetic twin-screw compressor	Semi-hermetic twin-screw compressor	Semi-hermetic twin-screw compressor		
	Quantit	у	1	1	1		
Energy adjus	stment n	node		Automatic			
Energy adjus	stment r	ange (%)		(25%, 50%, 75%,100%)			
	Name			R134a			
Refrigerant Charge (kg)			80	96	135		
Power supply			Three-phase five-wire system 380V/3P+N+PE/50Hz				
Safety protection			High pressure/Low pressure/Low water flow/Antifreeze/Motor overload/Low voltage/Open-phase protector/Phase sequence/Oil heater/Safety valve/Oil level				
	Туре		Shell-and-tube heat exchanger				
Water side	Water (t/h)	volume	65	86	102		
heat Water exchanger pressure (kpa)		side e drop	50	55	60		
	Inlet/ou diamete	tlet pipe er (mm)	DN125				
Water side fouling factor				0.086 (m ² .k/kw)			
l locit -llocit	L	.ength	3300	3500	3500		
Unit dime	nsions	Vidth	1200	1200	1200		
((()))	F	leight	1830	2113	2130		
Unit weight (kg)		2586	2790	3020		
Running wei	ght (kg)		2786	2990	3220		

Notes:

Midea®

- (1) Nominal cooling capacities are based on the following conditions: Chilled water inlet/outlet temp: 12℃/7℃; Indoor temp: 35℃.
- (2) Only performance parameters of the basic module are listed. You can obtain performance parameters of unit combinations by referencing the listed parameters.
- (3) The design pressure on the chilled water side is 1.0 Mpa.
- (4) The preceding specifications may be changed due to continuous improvement of products. The specifications on product nameplates and physical objects shall prevail.
- (5) The "Cooling input power" item include fan power.



Outdoor Unit

Model			MRH380A-B3Z MRH500A-B3Z MRH600A-B3Z		
Power sup	er supply Three-phase five-wire system 380V/3P+N+PE /50Hz			em	
Туре			Interna	l threaded pipes + alumir	num fins
	Fan Quantit	y	6	8	10
Air side	Air volume (m ³ /h)		23000x6	23000x8	23000x10
heat	Motor input	power (kW)	2.4x6	2.4x8	2.4x10
excnanger	Unit	Length	3500	4491	5600
	dimensions (mm)	Width	2280	2280	2280
		Height	2370	2370	2370
Unit weight	reight (kg) 1360 2070 2390			2390	
Running we	eight (kg)		1380	2090	2410

Notes:

- Nominal cooling capacities are based on the following conditions: Chilled water inlet/outlet temp: 12℃/7℃; Outdoor temp: 35℃.
- (2) Only performance parameters of the basic module are listed. You can obtain performance parameters of unit combinations by referencing the listed parameters.
- (3) The design pressure on the chilled water side is 1.0 Mpa.
- (4) The preceding specifications may be changed due to continuous improvement of products. The specifications on product nameplates and physical objects shall prevail.

2.2 Application Range

Content	Running Range			
Ambient temp.	10°C–43°C			
Outlet water temp.	5°C–15°C			
Water flow volume	Rated flow volume±20%			
Max inlet/outlet water temp. difference	38			
Voltage tolerance	Rated voltage±10%			
Phase tolerance	±2%			
Power supply frequency	Rated frequency±2%			
Evaporator max working pressure on water side	1.0 MPa			
Compressor max. start count	6 times/h			
	High corrosive environment and high			
	humidity should be avoided.			
	The height of water drainage should			
Drainage system	not be higher than the base of the unit			
	on the spot.			

3. Evaporator Pressure Drop Curve



4. Accessories and Models with Special Features

4.1 Standard Accessories

S/N	Name	Unit	Quantity	Specifications
1	Product certificate	Piece	1	
2	User manual	Piece	1	
3	Water flow controller	Piece	1	G1"
4	Packing list	Piece	1	

4.2 Optional Accessories

S/N	Name	Unit	Quantity	Specifications
1	Water switch	Piece	As required by customers	
2	Spring shock absorber	Piece	See the foundation diagram	
2		T IECE	in section 7.2.2.	

4.3 Models with Special Features

Certain models with special features can provide specific functions to meet various requirements of customers.

S/N	Туре	Function				Contents of Order		
1	High-temperature	The	maximum	allowed	ambient	The	maximum	ambient
1	refrigerating unit	temperature for refrigerating is 48°C.			temperature is specified.			
2			maximum	allowed	ambient	The	maximum	ambient
2	2 Oltra-temperature unit	temperature for refrigerating is 56°C.				temp	erature is s	pecified.
2	Dartial bast recovery unit		The heat of condensation released by the			The	heat	recovery
3 Partial neat-recovery unit		unit that can be partially recovered.			capacity is specified.			

5 Operating Principle

Àidea®

Air source screw water chiller comprises five major components including the compressor, finned heat exchanger, electronic expansion valve, shell-and-tube heat exchanger, and electric control system, and some auxiliaries such as the economizer. The basic circulation principle of the unit is shown in the following figure.

Operating principle of MLSC_A series units



6 Installation

6.1 Loading/Unloading and Hoisting (Diagram)

(1) Units should be loaded and unloaded carefully to avoid causing damage to unit components. Use a crane to load and unload units and use a forklift for short-distance transportation. A skid can ensure that the weight of units is evenly distributed on the base. In addition, three to six steel rods can be placed under the unit base to help slowly move the units, as shown in the following figure.

Diagram for horizontal movement



- (2) To hoist the units, pay attention to the following instructions:
 - Choose a suitable crane based on the unit's weight (buy insurance for it if possible).
 - Hoist the unit by using the method shown in the following figure. The steel rope shall wind the lifting hook one circle to prevent danger due to steel rope slipping when the weight is unbalanced.
 - Use an enlargement pole to prevent sling damage to the unit.
 - Strictly abide by the local safety regulations during hoisting. Only relevant personnel are allowed within the construction area. It is forbidden to stand under the crane or the lifted units.



Indoor units hoisting



Outdoor units hoisting



6.2 Requirements for Foundation Installation and Diagrams of Foundation

6.2.1 Requirements for Foundation Installation

Air-cooled screw units should be installed outdoors, for example, on the rooftop, ground, or near the buildings. Units must be installed on a solid foundation. A block of concrete slab is recommended, whose load-bearing capacity must be sufficient to withstand all the units, as well as the weight of maintenance personnel.

A spring shock absorber must be installed between the unit base and the foundation to avoid unit vibration and to prevent noise during unit installation. The position for placing the spring shock absorber and the points for load bearing are shown in the following figure.





6.2.2 Diagrams of Foundation MLSC380A



Madal	Weight to be supported by spring isolator (kg)					
Model	А	В	С	D		
MLSC380A-SB3Z	LSC380A-SB3Z MHD-850		MHD-850	MHD-850		



Notes: 1. The spring shock absorber is optional.

2. The value in the type of spring shock absorber indicates the maximum weight that the spring shock absorber can bear (unit: kg). For example, the number 1050 in MHD-1050 indicates that the maximum weight that the spring shock absorber can bear is 1050 kg.



MLSC500A

Indoor unit



Madal	Weight to be supported by spring isolator (kg)					
Model	А	В	С	D		
MLSC500A-SB3Z	MHD-1050	MHD-1050	MHD-1050	MHD-1050		

Outdoor unit



Madal	Weight to be supported by spring isolator (kg)					
A B C E					E	F
MRH500A-B3Z	MHD-650	MHD-650	MHD-650	MHD-650	MHD-650	MHD-650

Notes: 1. The spring shock absorber is optional.

2. The value in the type of spring shock absorber indicates the maximum weight that the spring shock absorber can bear (unit: kg). For example, the number 1050 in MHD-1050 indicates that the maximum weight that the spring shock absorber can bear is 1050 kg.



MLSC600A

Indoor unit



Model	Weight to be supported by spring isolator (kg)						
	А	В	С	D	Е	F	
MLSC600A-SB3Z	MHD-850	MHD-850	MHD-850	MHD-850	MHD-850	MHD-850	

Outdoor unit



Model	Weight to be supported by spring isolator (kg)						
	А	В	С	D	Е	F	
MRH600A-B3Z	MHD-650	MHD-650	MHD-650	MHD-650	MHD-650	MHD-650	

Notes: 1. The spring shock absorber is optional.

2. The value in the type of spring shock absorber indicates the maximum weight that the spring shock absorber can bear (unit: kg). For example, the number 1050 in MHD-1050 indicates that the maximum weight that the spring shock absorber can bear is 1050 kg.

6.3 Installation Space and Appearance

6.3.1 Installation Space Requirements for Outdoor Units

Enough space must be left around units and between units to ensure sufficient fresh air for air-side heat exchangers in units. In addition, the places around units must be kept clean without blocks. Otherwise, units maintenance could be inconvenient.

In areas where snows might fall in the winter, the following instructions should also be followed during unit installation:

(1) Do not install units under an eave of a house.



(2) Raise the foundation according to the possible snow height. (The foundation must be at least 1 m higher than the maximum snow height.)



(3) Do not install the unit at a place that might be piled with snow.





In areas where strong monsoon exists, if the unit's heat exchanger faces the direction from which the monsoon comes, the air flow will occur when the monsoon wind velocity is higher than the fan blowing velocity, as the dashed arrow shown in the following figure.



As a result, the cooled air flow will be cooled by another heat exchanger again. The refrigerating capacity will reduce and the unit can be faulty. Although air-cooled screw water chiller units have been designed to reduce the possibility of such circumstances, avoid installing the heat exchanger directly to the monsoon direction during unit installation.

If the heat exchanger must be installed facing to the monsoon direction due to geological limitations, a windbreak must be installed.

Windbreak installation



Midea®

- (4) Requirements for installing indoor units are as follows:
 - 1. The distance between the power control cabinet and the windbreak must be larger than 1,000 mm.
 - 2. The distance between the unit and the windbreak on the side of shell-and-tube end caps must be larger than 3,500 mm.
 - 3. The distance between the unit and the ceiling must be larger than 2,000 mm.

Midea

Air Source Screw Water Chiller Unit – Installation Operation and Maintenance Manual







6.3.2 Installation Requirements for the Pipe Connection Between Outdoor Units and Indoor Units (Supplementary)

6.3.2.1 Basic Piping Requirements

Operation processes are as follows:

Specify pipe route and dimensions based on the construction drawing> Prepare and in	stall the pipe
supports, hangers, and brackets \longrightarrow Prepare and place the pipe components \longrightarrow Perform	nitrogen
protection → Braze → Clean pipes → Test the air tightness → Seal the pipes w	ith insulation
materials — Perform vacuum drying	

6.3.2.2 Piping Principles for Refrigerants

ltem	Cause	Handling Procedure
Dryness	Meteoric water ingress\Engineering water ingress\Condensate water generated in the pipe	Standardize the processing Blast Vacuum
Cleanness	Products of oxidation in the pipe during welding, dust, and foreign matters	Introduce nitrogen when welding. Keep clean in processing the auxiliary pipes.
Gas tightness	Imprecise welding\Unqualified joint seal\Edge leakage	Use qualified welding rods. Strictly follow the welding operation specification. Gas tightness test Strictly follow the interface operation specification.

6.3.2.3 Horizontal Pipe Fixing

Refrigerant pipes may be deformed during the operation of air conditioners. For example, the length and direction of pipes may change. Hangers or brackets can be used to support the pipes. The installation instruction is shown in the following table.

Pipe Diameter (mm)	< Φ 60	Ф60-80	> Ф80
Distance Between Points of Support (m)	3	3.5	4

Typically, the gas pipe and liquid pipe must be suspended in parallel. The distance between points of support is determined based on the diameter of the gas pipe. The temperature of flowing refrigerant varies with the unit's operation and working status, and the refrigerant pipe expands when heated and contracts when cooled. Therefore, proper spaces must be left for the pipes after thermal insulation measures are taken. Otherwise, copper pipes may break due to stress concentration.

6.3.2.4 Riser (Vertical Pipe) Fastening

Midea

Risers are fastened along walls. Round mooma, instead of common insulation materials, is used at pipe straps. U-shaped pipe straps are installed outside the mooma. Anti-corrosion processing of mooma is required.

Pipe Diameter (mm)	< Φ60	Ф60-80	> Ф80
Distance Between Points of Support (m)	2.5	3.0	3.5

6.3.2.5 Local Fixing

Local fixing is required near the branch pipe, end pipe, and through hole on the wall to prevent stress concentration due to the stretching of pipes.

6.3.2.6 Moving and Storing of Pipes

- 1) Do not break the pipes when they are moved to the construction site.
- 2) Use end caps or adhesive tapes to seal pipe ends before the pipes are stored.
- 3) The coil must be placed vertically. Otherwise, the coil may become deformed due to its own weight.
- 4) Use wooden supports or acceptable substitutes to ensure that the copper pipes are placed at a place higher than the floor. This can prevent the pipes from being stained by dust or water.
- 5) Anti-dust and water-proof measures must be taken on both ends of pipes.
- 6) Pipes must be placed on a specified shelve in the construction site, or be placed in a specified area and looked after by a specified person.





6.3.2.7 Pipe Sealing

1) Optional measures of sealing are as follows:

- (1) Use end caps and adhesive tapes (for short-period storing)
- (2) Solder sealing (for long-time storing)

Note: Copper pipes must be sealed at any time during on-site construction as required.

• Sealing with end caps and adhesive tapes



This method is recommended.

• Solder sealing



2) Pay attention to the following operations:

(1) Dirt might be brought in when the pipe passes through a hole.



- (2) Rain water might enter the copper pipe through the outdoor parts of the pipe, especially when the pipe is installed vertically.
- (3) Pipe ends must be covered before finishing the pipe connection.
- (4) Place the pipe ends horizontally or downward.



(5) Cover the pipe end temporarily when the pipe is being installed through a wall.



(6) Do not directly place the pipe on the ground. Do not rub the pipe against the ground.



(7) In the case of rain, cover the pipe end before installation.



6.3.2.8 Copper Pipe Processing

1) Pipe Cutting

(1) Tool

Use a drill-pipe cutter, instead of a saw or cutting machine to cut the copper pipe.

(2) Correct operation procedure

Turn the drill-pipe cutter slowly while keep stressing. The copper pipe can be cut without being deformed.

(3) Reasons for not using a saw or cutting machine for pipe cutting

If a saw or cutting machine is used, copper cuttings remained in the pipe may be brought into the compressor and block the flow control components.



2) Copper Pipe End Trimming

(1) Purpose

Remove the burr on pipe ends and clean the inner space of pipe. In this way, no scratch will occur on the sealing interface during pipe end expansion.

- (2) Operation method
 - ① Use a scraper to remove the burr in the inner side of the pipe end. Slope the pipe downwards; otherwise, copper cuttings may enter the pipe.
 - ② Chamfer the pipe, and then use cotton gauze to clean the copper cuttings inside the pipe.
 - ③ Do not make any scratches. Otherwise, the pipe may break during end expansion.
 - ④ Cut the part that is severely deformed and start from a new end.

3) Pipe Expanding

- 1. Purpose: Expand the pipe end to enable the insertion of copper pipe. In this way, less soldering point is required.
- 2. Note: Parts for connection must be smooth. Remove the burrs in the inner side of pipe end.
- 3. Operation method: Insert the head of the pipe expander into the pipe. After the pipe is expanded, view the copper pipe from another angle and maintain the pipe end and left a straight line mark.



6.3.2.9 Soldering

Nitrogen protection during copper pipe soldering

1) **Purpose**: Prevent the generation of oxide skin inside the copper pipe due to high temperature.

2) Disadvantages of soldering without nitrogen protection:

Without sufficient nitrogen being filled into the refrigerant pipe that is being brazed, the inner surface of copper pipe will be oxidized. The generated oxide will block the refrigerant system and deteriorate the lubricant in the compressor. As a result, the compressor will burn and the performance of air conditioner will decrease.

Therefore, nitrogen must be filled into the refrigerant pipe continuously during soldering. Ensure that the nitrogen flow can reach every soldering point until the soldering is finished and the copper pipe returns to the ambient temperature. Set the nitrogen pressure appropriately. Excessive pressure may cause bubble



and blisters at soldering points, or even soldering failure. Nitrogen protection diagram is as follows.



3) Preparing the connector of nitrogen-filled hose

Connect the nitrogen-filled hose to the pipe component to be soldered and seal all other pipe ends except for the soldering end which is used for nitrogen filling.

4) Precautions for soldering pipe components

- (1) Use the transition fitting instead of flared pipe to connect pipe components.
- (2) Fill in the nitrogen from the short pipe side to get a better nitrogen replacement.



5) Standard soldering operations





6) Operation requirements

- During soldering, the nitrogen pressure must be controlled within the range of 0.2 kgf/cm² to 0.3 kgf/cm².
- (2) Only nitrogen is used. Do not use oxygen or other inflammable or combustible gases. Otherwise, explosion may occur.
- (3) A pressure reducing valve is required. The pressure of filled-in nitrogen must be 0.2 kgf/cm².
- (4) Select a proper place for nitrogen filling.
- (5) Ensure that the nitrogen flow can pass the soldering point.
- (6) If the distance between the place where nitrogen is filled in and the soldering point on the pipe, fill in enough nitrogen and ensure that all nitrogen flow at the soldering point can be vent.
- (7) Keep filling nitrogen after the soldering is completed until the pipe returns to the ambient temperature.
- (8) The soldering should be performed from top to bottom, or horizontally. Avoid face-down bonding.



7) Precautions

- (1) Watch out for fire during soldering (prepare fire extinguishers as required).
- (2) Be careful during soldering and avoid being burned.
- (3) Leave proper distances between pipe sockets.

6.3.2.10 Pipe Blowing

1) Blowing of copper pipe

- (1) Principle of operation: Blow pressure gas into pipes (raw material pipes or soldered components) to remove the dust and water inside the pipes. (Solid impurities cannot be removed; therefore, relevant protective measures must be taken during implementation.)
- (2) Purpose
 - ① Remove the oxide power or part of the oxide skin inside the copper pipe.
 - 2 Remove the impurities and moisture inside the pipe.
- (3) Reason

If pipe blowing is not performed, solid impurities and water inside the pipes cannot be removed. As a result, ice plug, filth blockage, compressor failure, and other severe problems may occur.

2) Preparation

- Install the pressure regulator valve on the nitrogen cylinder. (Use nitrogen instead of any other gas, because Polyter afuoroethyenea or carbon dioxide may cause condensation, and oxygen may cause explosion.)
- (2) Use a gas tube to connect the outlet of pressure regulator valve and the inlet of gas pipe/liquid pipe of outdoor unit.
- (3) Block the joint of copper pipe with a blind plug and blow each branch pipe. During soldering, blow and clean each pipe after the pipe is soldered. When all pipes are soldered, clean the pipe system again.
- (4) Open the valve of the nitrogen cylinder and set the regulator valve to 5 kgf/cm2.

3) Operation procedure

- (1) Use proper plugging materials (for example, a wood brick wrapped with cotton cloth) to block the end of the major air pipe of indoor unit.
- (2) Release the plugging materials suddenly when you cannot resist the pressure in the pipe. Until now, the pipe is blown and cleaned for one time.

Then, repeat step 1 and step 2 to blow and clean the pipe many times.



(3) Put a piece of cotton cloth loosely near the pipe end. In this way, you can detect the dirt and


moisture that are cleaned out from the pipe and clean the pipe thoroughly.

Specific measures are as follows:

(1) Use nitrogen to flush dirt and moisture out of the pipe.

2 Perform vacuum drying.

- ③ Close the main valve of the nitrogen cylinder.
- ④ Repeat the preceding steps on all connection copper pipes of indoor unit.

(5) When all pipes are connected and a pipe system is formed, blow and clean the pipe from the far end. That is, the end of the pipe that is the farthest from the master unit.

⁽⁶⁾ Cover all pipe ends that are directly exposed to the external environment when the blowing and cleaning process is finished. Otherwise, dusts, foreign matters, and moisture may enter the pipes again.

6.3.2.11 Air Tightness Test

6.3.2.11.1 Purpose and Operational Sequence

1) Purpose

Check the leak source and ensure that no leakage exists in the entire system. In this way, no system failure due to refrigerant leakage will occur.

2) General principle

Inspections in different phases, pressure maintaining for the entire system, and pressure increasing in steps.

3) Operational sequence

- Connect the pipes of outdoor unit. Then, use a U-shaped connector to connect the gas pipe and liquid pipe. Meanwhile, increase the air pressure in the pipe by injecting dry nitrogen.
- (2) Connect a copper pipe with a joint to the gas pipe or liquid pipe to allow the nitrogen flow.



6.3.2.11.2 Operation Steps

1) Precautions

- (1) Ensure that the valves of gas pipe and liquid pipe are closed. Do not open the ball valve on the indoor unit during pressure increasing, because nitrogen may enter the circulation system of indoor unit.
- (2) For a refrigerant system, increase the pressure slowly from both sides of gas pipe and liquid pipe by sequence.



Midea®

Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

(3) Only dry nitrogen can be used as the medium for air tightness test. The pressure increasing in difference phases is shown in the following table.

C/N	Phase (Pressure la Ingressed in Different Phases)	Accept	tance
3/11	rhase (riessure is increased in Different rhases)	Criterio	on
4	Phase one: Large leak sources can be detected if the air pressure		
1	is kept at 3.0 kgf/cm ² for over three minutes.	No	pressure
2	Phase two: Relatively large leak sources can be detected if the air	drop	after
2	pressure is kept at 12.0 kgf/cm ² for over three minutes.	pressu	ire
2	Phase three: Tiny leak sources can be detected if the air pressure	correct	tion
3	on R134a is kept at 20.0 kgf/cm ² for over 24 hours.		

2) Pressure observation

- (1) Increase the pressure of 20.0 kgf/cm² on R134a in the pipe and maintain the pressure for 24 hours. If the pressure does not drop after it is corrected based on the temperature change, the test is passed. If the pressure drops, find and repair the leak source.
- (2) Compensating method

The pressure increases/drops by 0.1 kgf/cm² when the ambient temperature increases/drops by 1° C.

Compensating formula: Actual value = Pressure during pressure increasing + (Temperature during pressure increasing – Temperature during observation) x 0.1 kgf/cm²

Compare the compensated value with the original pressure to see whether the pressure drops.

(3) Methods for checking leak sources

During the three phases, if pressure drops, use the following methods to find the leak sources:

① Leak detection by ears: Air leakage of large leak sources can be heard.

② Leak detection by hands: Touch pipe connections to feel whether any air leaks.

③ Leak detection by soapsuds: Apply soapsuds on pipes. Bubbles will appear at leak sources.

(4) Leak detection by halogen leak detector

A halogen leak detector is used when a tiny leak source is found, or when the leak source cannot be found in the case of pressure drop during pressure increasing test.

a. Set the nitrogen pressure to 2.0 kgf/cm².

b. Add the refrigerant and set the pressure to 3.0 kgf/cm².

c. Use the halogen leak detector, alkane gas detector, and electric detector to check for leak sources.

d. If no leak source is found, increase the pressure on R134a to 20.0 kgf/cm² and check again.

3) Precautions

① Compressed nitrogen (R134a system: 20 kgf/cm²) is used for the air tightness test.

② Oxygen, inflammable gases, or toxic gases cannot be used for an air tightness test.

③ Wait until the pressure is stable before you record the temperature, pressure, and time (for correction).

④ After the pressure maintaining is finished, reduce the system pressure to 5 to 8 kgf/cm² before sealing the pipes.

⑤ Check long pipes section by section.

6.3.2.12 Vacuum Drying

6.3.2.12.1 Purpose and Key Points

1) Purpose

- (1) Remove water from the system and avoid ice plug and copper plating (ice plug will cause system malfunction and copper plating will shorten the lifespan of compressor).
- (2) Remove incoagulable gas (air) from the system to avoid system components oxidation, system pressure fluctuation and inefficient heat exchange during operation.
- (3) Check for system leakage from the opposite direction and keep the negative pressure.

2) Selection of vacuum pump

- (1) The extreme vacuum degree must be -756 mmHg or lower.
- (2) The displacement must be 8 liter/s or higher.
- (3) The precision must be at least 0.02 mmHg.

3) Vacuum drying of pipe

A vacuum pump is used to change the water (liquid) in pipes to gas and remove the gas from pipes. As a result, the pipes are dry. In the case of atmospheric pressure, the boiling point (vapor temperature) of water is 100°C. The water in a vacuum pump has a lower boiling point. When the boiling point is lower than the ambient temperature, the water in the pipe will evaporate.

Boiling Point of Water (°C)	Air Pressure (mmHg)	Vacuum Degree (mmHg)	Boiling Point of Water (°C)	Air Pressure (mmHg)	Vacuum Degree (mmHg)
40	55	-705	17.8	15	-745
30	36	-724	15	13	-747
26.7	25	-735	11.7	10	-750
24.4	23	-737	7.2	8	-752
22.2	20	-740	0	F	750
20.6	18	-742	0	5	-756

6.3.2.12.2 Vacuum Drying Procedure

1) Methods

Common vacuum drying and special vacuum drying are applicable to different environments.



Note: The vacuum drying procedure must be strictly performed for all systems. Otherwise, ice plug will occur.

(1) Procedure for common vacuum drying

(1) Vacuum drying (the first time): Connect the pressure measuring set to the stop valve of the liquid pipe and gas pipe. Then, start the vacuum pump and keep it running for over two hours. (The vacuum degree should be lower than -756 mmHg.)

② If the vacuum degree cannot reach a value lower than −756 mmHg after two-hours' pumping, it indicates that water or leak source exits in the pipe system. In this case, keep pumping for another one hour.

③ If the vacuum degree cannot reach a value lower than -756 mmHg after three-hours' pumping, check for leak sources.

④ Perform pumping from the directions of both the liquid pipe and gas pipe.

(5) Vacuum stability test can be performed when the vacuum degree **reaches –756 mmHg**. If the hand of the vacuum gauge does not point to a larger value after one hour, it indicates that no water or leak source exists. If the hand of the vacuum gauge points to a larger value after one hour, it indicates that water or leak source exists.

Note: It is forbidden to remove the pressure gauge during vacuum pressure maintaining process. Otherwise, external air will be taken in.

(2) Procedure for special vacuum drying

Special vacuum drying is applicable to the following scenarios:

① Water is detected during the blowing and cleaning of refrigerant pipe.

2 Rain water may enter the pipe in the rainy season.

③ Rain water may remain in the pipe since the pipe is not checked for a long time.

④ Rain water may enter the pipe during construction.

The procedure for special vacuum drying is as follows:

a. Vacuum drying (the first time): Keep the pump running for two hours.

b. Vacuum breaking (the first time): Fill nitrogen into the pipe. The pressure is 0.5 kgf/cm².

Dry nitrogen can dry out the inner part of pipe. However, the inner part of pipe cannot be thoroughly dried out by using this method if too much water exists. Therefore, avoid water inflow and condensate water during refrigerant piping.

c. Vacuum drying (the second time): Keep the pump running for one hour.

Determining the result: When the vacuum degree is lower than –756 mmHg, the test is passed. If the vacuum degree cannot be lower than –756 mmHg after two-hours' pumping, repeat step b and step c.

Note: Maintain system pressure after vacuum drying is completed. Keep the pipe in vacuum for one hour. If the pressure does not rebound, the test is passed.

6.3.2.13 Refrigerant Recharge

6.3.2.13.1 Procedure

1) Operation steps

- (1) Ensure that vacuum drying is completed.
- (2) Calculate the amount of refrigerant to be recharged (based on the recommended value, actual liquid pipe dimensions, and length specified in section 7.3.3.1).
- (3) Use an electric balance to weigh up the required refrigerant.
- (4) Connect the refrigerant cylinder, pressure gauge, and the service valve of outdoor unit with flexible ducts. Vent out the air in the flexible ducts and the branch of pressure gauge. Then, fill in the refrigerant in liquid state.
- (5) Write down the amount of recharged refrigerant on the nameplate of the outdoor unit.

Precautions

① The amount of recharged refrigerant must be calculated based on relevant technical instructions specified in the accessories of indoor unit, instead of based on the current, pressure, or exhaust temperature. Because the system current, pressure, and exhaust temperature vary with the ambient temperature and pipe length.

② If the temperature is low, the refrigerant cylinder can be warmed by using warm water or hot air, instead of being heated up above fires.

6.3.2.14 Thermal Insulation

Common thermal insulation is applied to refrigerating devices and pipes. To be specific, devices and pipes are wrapped by solid and porous thermal materials. Together with proper moisture-proof and protective measures, a thermal insulation structure is created. The thermal insulation structure varies with the type of thermal material. Although the thermal insulation performance of this traditional method is not remarkable, the simple structure, convenient construction, and cost effectiveness make it broadly used in the industry.

6.3.2.14.1 Thermal Insulation of Refrigerant Pipe

1) Operation procedure

Refrigerant pipe construction Thermal insulation (except for the connectors)

Thermal insulation of connectors such as the soldering area, expanding area, and flange can be performed only after the air tightness test is passed.

2) Purposes

- (1) When the air conditioner is running, the temperature of gas pipe and liquid pipe can be either too high or too low. Without thermal insulation, the refrigerating performance can be affected. In addition, the compressor may be burned.
- (2) The gas pipe temperature is very low during refrigerating. If no thermal insulation measure is

Midea®

Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

taken, condensation may occur and lead to leakage.

(3) During the heating process, the temperature of outlet pipe (gas pipe) is usually high (50°C to 100°C). People may be burned if they accidentally touch the pipe.

3) Selection of thermal materials

Polyurethane foam (flame retardant: B1; heat resistance: over 120°C)

4) Thickness of insulating layer

When $d \ge \Phi 40$ mm (d indicates the external diameter of the copper pipe), $\delta \ge 25$ mm (δ indicates the thickness of insulating layer).

Note: Thicker insulating layer should be used in the hot and humid scenario.

Note: Outdoor pipes must be protected with metal shell to prevent the pipes from the sun, rain, wind, and man-made sabotage.

5) Installation process and precautions

(1) Examples of incorrect operation

The gas pipe and liquid pipe are bound together. As a result, the insulating performance is bad.



- (2) Examples of correct operation
- a. Perform thermal insulation on the gas pipe and liquid pipe separately.



OK

Note: After thermal insulation is performed separately on the gas pipe and liquid pipe,



over-tightened bandage can break the thermal insulation connector. Therefore, do not use bandage.

b. Ensure the insulating performance of pipe connectors.





(3) **Precautions**

 $(\ensuremath{\underline{1}})$ There should be no gap between joints of insulating materials.

⁽²⁾ If the bandage around the joints of insulating materials is too tight, cracks and condensation may occur, air in the materials will be squeezed out, and the insulating performance will be affected. In addition, the bandage will age and scatter as the time passes by.

③ Bandage is not required in hidden indoor places. Otherwise, the insulating performance will be affected.

Correct method for repairing the insulating cotton is shown in the following figure:



Prepare a piece of insulating cotton that is longer than the gap. Insert the insulating cotton inside the gap and glue the joint.

(4) **Precautions**

- ① The length of the insulating cotton for gap filling is 5 to 10 cm longer than the gap.
- 2 The cut and section of insulating cotton must be smooth.

③ Insert the insulating cotton tightly into the gap.

④ All cuts and sections must be glued.

(5) Wrap the joint with bandage.

6 Bandage is not required in hidden indoor places. Otherwise, the insulating performance will be affected.

6.3.3 Recommended Pipelines Between Indoor Units and Outdoor Units

6.3.3.1 Dimensions of Connection Pipes

When the distance between the indoor unit and outdoor unit is between 0 to 15 m, 15 to 30 m, or 30 to 50 m, and the difference of the height of indoor unit and outdoor unit is not greater than 6 m, respectively install the recommended connection pipes shown in the following table. Refrigerant and lubricant can be recharged properly based on the dimensions of connection pipes by referring to the table.

	0 to 15 m	ו	15 to 30	m	30 to 50	m	Amount of	Amount of
Madal							Refrigerant	Lubricant
woder	Vent	Liquid	Vent	Liquid	Vent	Liquid	to Be	to Be
	pipe	pipe	pipe	pipe	pipe	pipe	Recharged	Recharged
MLSC380A-SB3Z	2 ⁵ / ₈ in	1 ⁵ / ₈ in	2 ⁵ / ₈ in	1 ⁵ / ₈ in	2 ⁵ / ₈ in	1 ⁵ / ₈ in	1.4 kg/m	0.07 L/m
MLSC500A-SB3Z	Z 3 in 1 ⁵ / ₈ in		3 in	1 ⁵ / ₈ in	3 in	1 ⁵ / ₈ in	1.4 kg/m	0.07 L/m
MLSC600A-SB3Z	3 ⁵ / ₈ in	2 ¹ / ₈ in	3 ⁵ / ₈ in	2 ¹ / ₈ in	3 ⁵ / ₈ in	2 ¹ / ₈ in	2.5 kg/m	0.12 L/m

Incorrect installation of vent pipe through a wall





Correct installation of vent pipe through a wall



When the difference of the height of indoor unit and outdoor unit is greater than 6 m, you are advised to install the vertical part of the vent pipe in the method shown in the following figure. The specifications of connection pipe are selected by referring to the following table. However, specifications of the horizontal part are still selected by referring to the preceding table.



Recommended external diameters of connection pipes when the vertical part of the vent pipe comprises two pipes

	Connection	Length of th	e Connection	Length	of	the			
Madal		Connection P							
Model	Vont Dino	Pipe (m)		Liquid Pipe (m)					
	ventripe	0~15	15~30	30~50	0~50				
MI 60290A	А	2 ¹ / ₈ in	2 ¹ / ₈ in	2 ⁵ / ₈ in	1 ⁵ / in				
MLSC300A	В	2 ¹ / ₈ in	2 ¹ / ₈ in	2 ⁵ / ₈ in	1 /8 111				
MI SCEOOA	А	2 ⁵ / ₈ in	$2^{5}/_{8}$ in $2^{5}/_{8}$ in $2^{5}/_{8}$ in		-1^{5} / in				
MLSCOUA	В	2 ¹ / ₈ in	2 ¹ / ₈ in	2 ¹ / ₈ in	1 /8 111				
MISCEOOA	А	3 in	3 in	3 in	01/ :				
WESCOUR	В	2 ⁵ / ₈ in	2 ⁵ / ₈ in	2 ⁵ / ₈ in	∠ / ₈ III				



Installation diagram when the vertical part of the vent pipe comprises a single pipe



6.3.3.2 Lubricant Recharge

When the connection pipes are installed and the inner part of the pipes are clean and vacuum (the vacuum degree is –756 mmHg or lower), lubricant can be recharged. To recharge lubricant, use an oil pump (either manual or electric) to inject lubricant to the liquid pipe by referring to the recommended amount specified in section 7.3.3.1.

Note: Lubricant brand: BSE 170



6.3.4 Unit Appearance

Appearance of MLSC380A(500/600) indoor unit



Model MLSC_A	L	W	Н	A	В	С	D	E	F	Inlet condenser interface	Outlet condenser interface	Frozen water interface
380	3300	1200	1830	2330	848	175	539	1824	860	φ 67	φ 42	DN125
500	3500	1200	2113	2344	1054	197	745	2020	410	φ 80	φ 42	DN125
600	3500	1200	2130	2345	1053	200	754	2029	410	φ 92	φ 42	DN125



Appearance of MRH380A-B3Z(500/600) outdoor unit





Model MRH_A	L	W	Н	A	В	С	D	Inlet condenser interface	Outlet condenser interface
380	3500	2280	2370	1335	1170	250	255	φ 67	φ 42
500	4491	2280	2370	1226	1046	250	268	φ 80	φ 42
600	5600	2280	2370	1244	1020	250	268	φ 92	φ 42

6.4 Requirements for Water System Installation and Recommended

Diagram for the Water System

6.4.1 Requirements for Water System Installation

When installing the water system, you must follow general installation rules to achieve the maximum working efficiency. There should be no foreign matter in pipes, and all chilled water pipes must be in accordance with local pipeline engineering procedures and regulations.

- A safety valve with the opening pressure not higher than 1.0 MPa must be installed.
- The chilled water pipeline must be cleaned in a by-pass manner. It is prohibited to connect the evaporator to the water system before pipelines are washed.
- During piping construction, sufficient space must be left for maintenance. In addition, ensure that a water escape valve can be installed and maintained on the piping of the water system of the unit.
- The unit is not equipped with a water pump. You must install a water pump that matches the impedance of the piping.
- All pipelines should be straight and simple, because elbow pipes, tee joints, and valves will reduce pump capacity.
- You are advised to install manual stop valves in all pipelines for easy maintenance.
- A drain pipe must be installed in each low position so that the evaporator and pipeline can drain water thoroughly.
- A deflation valve must be installed on the top position of the chilled water pipe in order to vent the air inside pipelines. For easy maintenance, thermal insulation at deflation and drain pipe joints is not required.
- When the chiller is not in use in winter or stops running at night, you must take anti-freezing measures (such as drainage, water circulation pump running, and heater heating) to protect the water loop if the ambient temperature is lower than 0°C. If the water loop is frozen, the dry expansion evaporator may be damaged. Therefore, you must take an appropriate measure based on actual conditions.
- Measures should be taken to ensure the cold-preservation, heat-preservation, and damp proof of water piping. If cold-preservation and heat-preservation are not sufficient in severe winter, in addition to possible heat loss, the machine may be damaged due to freeze.
- The quality standard for the chilled water is used as the quality standard for the circulating water. Any water leakage may cause corrosion.
- Water quality must comply with the JRA-GL-02 standard.
- The amount of the water retained in the system should be in the operating range. Water insufficiency will result in scale deposition, thereby causing performance loss or pitting corrosion, and finally leading

to refrigerant leakage. An overlarge water flow will cause corrosion.

Àidea[®]

- Do not expose the water in the circulating system to the air, as shown in the following figure.
- If water is exposed to the air, the amount of the dissolved oxygen will increase, and atmosphere pollutants will coagulate in water. As a result, water may be corrosive.



- Do not connect any other electric appliances to the ground, and then to the water piping of the unit. This may cause electrolytic corrosion of the water piping.
- Anticorrosive measures must be taken for buried piping.
- To prevent generation of air pockets, pay attention to the water flow speed in the water pump system and the positions of the expansion tank and the exhaust plug.
- If the pH value of the water exceeds the standard value, the corrosion of coppers will be accelerated. Therefore, change the water before the pH value reaches the standard value. If the heat storage tank is still in use after expiration, the cracks on the heat storage tank may cause water splashing and leakage. Water leakage will not cause serious problems to water quality control. However, if sea water or polluted underground water spills, microorganisms may breed in the water heat storage tank. This will generate debris in the system and cause the adhesion of calcium carbonate.
- A flexible tube should be installed on the unit and on the water inlet and outlet pipes of the water pump, to prevent the vibration in water pipes from being transmitted to buildings.
- A drainpipe must be installed at all water outlets. Pay attention to the front and behind distribution of the water inlet and outlet. Observe the identification label on the unit carefully. Do not make a mistake.
- Based on engineering requirements, the design of the evaporator's water inlet and outlet pipes must follow the following criteria:
 - a) The outlet of the circulation pump in the pipeline must be connected to the inlet of the evaporator.
 The inlet of the pump must be connected to the water return pipeline instead of the evaporator.
 - b) A water stainless steel strainer with more than 25 meshes must be installed on the inlet pipeline of the evaporator.
 - c) Before you run the unit, clean all chilled water pipelines thoroughly and remove all foreign matters.
 Do not crush any foreign matter into the evaporator.

Midea

- d) For easy inspection and repair, a thermometer and a pressure gauge must be installed on the water inlet and outlet pipes.
- e) A water flow switch must be installed on the water outlet pipe of each evaporator. Both ends of the water flow switch must be a horizontal straight pipe with the length more than five times of pipe diameter. The paddle of the water flow switch must be adjusted based on the specifications of the pipe. For details, see the water flow switch manual provided by the manufacturer. The water flow switch is connected to the terminal on the control box. For details, see the electrical wiring diagram.

WARNING

When installing the water flow switch, you must confirm the water flow direction.

The water flow switch is just a safety switch. It is prohibited to use it to start or stop the unit.

• When multiple chilled water units share the same water system, the pipes of these units must be connected in different modes, as shown in the following figure, to avoid large unbalance of water flow in the units.



6.4.2 Recommended Diagram for the Water System

6.5 Electrical Installation

6.5.1 Electrical Wiring Notes:

- A dedicated power supply must be used for the air conditioner. The voltage of the power supply must comply with the rated voltage.
- (2) The wiring construction must be carried out by professional technicians based on the circuit diagram label.
- (3) The power and ground cables must be tightened by using an appropriate tool with a proper torque.
- (4) The power and ground cables must be crimped securely and checked from time to time to prevent looseness.
- (5) Only electrical components specified by our company can be used, for which you must request the manufacturer or authorized dealer to provide related installation and technical services. If the wiring does not meet the electrical installation standard, the controller may work improperly or an electric shock may occur.
- (6) An incoming circuit breaker must be installed on the fixed line.
- (7) Electric leakage protection devices must be set correctly based on the requirements in relevant technical standards of electrical equipment.
- (8) The power supply can be connected only when no error is found after all wiring operations are complete.
- (9) Read each label attached on the electric control box carefully.
- (10) Do not try to repair the machine by yourself. If the controller is repaired improperly, an electric shock may occur or the controller may work improperly. If you have any repair demand, contact the repair center of after-sale.



Cable Selection Criteria for Units

Model	Recommended Power Cable	Recommended Breaker Capacity	Remarks
MLSC380A-SB3Z	BVR120*4+BVR70*1	330 A	Copper core cables must be used
MLSC500A-SB3Z	BVR240*4+BVR120*1	500 A	for the unit. If the unit is used in
MLSC600A-SB3Z	BVR240*4+BVR120*1	500 A	the breaker may decrease. In this case, you must expand the breaker's capacity appropriately.
MRH380A-B3Z	BVR16*4+BVR10*1	100 A	
MRH500A-B3Z	BVR25*4+BVR16*1	100 A	
MRH600A-B3Z	BVR25*4+BVR16*1	100 A	

Common Cables

BVR: Copper	core PVC inst	ulated soft wire			
Domestic Model	Conductor Material	Insulator Material	Nominal Cross-Section Area (mm²)	UL Model	Remarks
BVR70	Cu	PVC	70	2/0	
BVR95	Cu	PVC	95	4/0	
BVR120	Cu	PVC	120	250	Only copper core cables
BVR150	Cu	PVC	150	300	can be used for the unit.
BVR185	Cu	PVC	185	400	
BVR240	Cu	PVC	240	500	

Maximum electricity transmission distance

Maximum load time in a year (h)	Length of copper core cable (m)
< 3000 h	264
3000–5000 h	294
> 5000 h	331



6.5.2 Power Supply Specifications and Use Environment

The unit must run in the following environment: Outdoor temperature: 10° to 43° Altitude: ≤ 1000 m Power supply frequency: $50\pm2^{\circ}$ Hz Voltage: $380\pm10^{\circ}$ V

6.5.3 Power Supply Requirements

The power supply must comply with the calibration values on the nameplate of the unit.

WARNING

The unit will generate an alarm if the voltage is abnormal. If the three-phase voltage unbalance of the unit exceeds 2% or if the current unbalance exceeds 10%, contact the local electric power department immediately and keep the unit in the stopping state.

Voltage unbalance = Difference between average three-phase voltage and maximum voltage Average three-phase voltage

An unbalanced voltage will cause phase-to-phase current unbalance at motor terminals. For a fully loaded motor, current unbalance changes in a range of 6–10 times of voltage unbalance. In this case, the motor current will be overlarge, resulting in overheating of the motor. As a result, the compressor lifespan becomes short, and even the motor may be burnt. In addition, an overlarge unbalanced voltage will reduce the torque. As a result, the operation requirement cannot be met, and the motor fails to run due to low speed.

The minimum startup voltage of the unit must be kept higher than 90% of the rated voltage.

6.5.4 Requirements for Wire Connection

(1) Specifications for the main power cable must comply with relevant national regulations. The protective ground power supply must be taken from the site. The grounding resistance must comply with relevant national standards. After the cable connection is complete, install a waterproof, dustproof, and a sealing device in the wire inlet hole of the main power cable. Our company will not take any responsibility for any electrical accident arising from poor ground connection or careless operation.



Wiring diagram for the main power cable of the indoor unit



External wiring diagram for indoor units of the MLSC380A-SB3Z, MLSC500A-SB3Z and MLSC600A-SB3Z series.

Note: All inputs must be passive dry contacts, and all outputs must be transferred by using an intermediate relay.



Wiring diagram for the main power cable of the outdoor unit



External wiring diagram for outdoor units of the MRH380A, MRH500A, and MRH600A series. Note: The indoor and outdoor units must be supplied power independently. If the unit is not in use for a long time, you can cut off the main switch in the power distribution cabinet. When maintaining the unit, you must cut off the main switch and prevent accidental switch-on. Midea®

Electrical wiring diagram for the indoor and outdoor units



Electrical wiring diagram for the indoor and outdoor units of the 380/500/600 series

Note: The above figure shows the diagram for connecting the fan's control signal wires and motor overload feedback signal wires. Customers must connect these wires on the installation site by using a shielded wire. (The fan's control signal wires 79, 83, 87, 91, 95, and 99 can share the same wire. For details, see the circuit diagram label delivered together with the unit.)

- (2) You must use a cable with correct specifications to provide electric power for the unit. The unit must be supplied power independently. It is prohibited to connect the unit and other appliances to the same power supply. Otherwise, overload risk may be presented.
- (3) The power cable length must ensure that the voltage drop between the start and end of the power cable is smaller than 2% of the rated voltage during unit operation. If the power cable cannot be shortened, it must be thickened.
- (4) The wiring between the power supply and unit must be constructed strictly according to the National Electrical Code and must be well-insulated. After unit wiring, use a 500 V megger to test the insulation resistance between the electrical accessory terminals and the unit. The insulation resistance must be at least 10 MΩ.
- (5) According to the National Electrical Code, the shell of the unit must be protected by a reliable ground device to prevent electric shock accidents, thereby protecting human bodies.

- (6) It is prohibited to pass power cables and control wires that are not connected to the electric control box through the electric control box. Otherwise, the unit and controller may be faulty or even be damaged due to electromagnetic interference, and the protection may fail.
- (7) All weak electric wires connected to the electric control box must adopt shielded wires, and a ground wire must be installed at the shielded layer. The shielded wires and power cables must be laid in different places to avoid electromagnetic interference.

6.5.5 Wiring Procedure

λidea

- Ensure that the unit is connected to the ground cable correctly to prevent electric leakage accidents. Constructions for grounding devices must be carried out strictly according to the National Electrical Code. Ground cables can resist electric shocks.
- (2) Install the control box of the main power supply switch at an appropriate position.
- (3) Install a sealing device in the wire connection hole of the main power supply.
- (4) Pass the main power supply, neutral wire of power supply, and ground wire through the wire connection hole, and then connect them to the electric control box.
- (5) Keep the phase sequence consistent when connecting the main power supply.
- (6) Install the main power supply at a position that can be accessed only by dedicated maintenance personnel to prevent misoperation and ensure safety.
- (7) Use an inching switch when connecting remote control wires. For details, see the wiring diagrams in the appendix.
- (8) Prepare a water flow switch by yourself when connecting the control wires of the water flow switch. For details, see the wiring diagrams in the appendix.
- (9) For details about how to connect the control wires of the water pump, see the following figure.



Àidea®



Wiring Diagrams

Wiring diagrams for MLSC380A-SB3Z, MLSC500A-SB3Z and MLSC600A-SB3Z





Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual









Air Source Screw Water Chiller Unit – Installation Operation and Maintenance Manual

	A	В	ç	0	Li Li	ł.	9	н
				2E				
		E E		-2/				
12		-6/1		≜		/2C		2
		▲ ▲			1			
			5					
			<u> </u>		23 (A7	Fan Group 6		
			123	614	h	🛶 🛛 Fan Group 5		
=					L KA 2			=
			122		19 (A5	Fan Group 4		
Ц			[2]			- Fan Group 3		
	Service Switch	1		- <u>±</u>				
	(Short Circuit)		$13(1)$ 38^{29}			+ •		
8	EVD Fault				└ <u>──</u> ───	Fan Group a		8
	(Short Circuit)	A1 A1	X:5 3(TE TE			
	C/H Mode Switch			610	475 I 3	🔶 🛛 Fan Group 1		
	Power Protection Switch						Volve	
	For availand Prot Switch				X: 7			
σ	(The user connected)	: 32	36	8	0 0 1 2 2 1 0 1 0 0	🔶 🛛 75% SOL. 1	Valve	0
			X:	,	YV IX:			
Ц			0W2	AH IS	\boxtimes	[
	Comp. Overload Prot. Switch			ZP] ₩	3 J 2 4 4	-+ 50% SOL. V	/alve	
	Dil Pressure Differ. Switch	╢ │ ゛゛゚゙゚	~ +				Valvo	
0	(Short Circuit)	F	11	40	X:2 X:2 X:2		vu(Ve	00
	Dil Level Switch					Fan Start	Signal	
			2 2		X:3		/01	
	Lontactor Protection			8I 07		Lomp. Star	:/Stop	
	Conp. Motor Prot. Switch					🔶 🛛 Water Pu	mp	
~		So X:4	0 1X:4		X:1: X:1			~
	Low Pressure, Switch		11					
	High Pressure Switch			Al h				
		SP1 X:4	X:3			Service Switch	1	
	Anti-Freeze Switch	02 37	1380 II		<u>[</u>	ை (Short Circuit)	
0	Water Flow Switch					X:2		2
		X:6	X:51					
Ц	Remote Stop		I 10		<u>[</u>	+ •		
	Remote Start	┝┷┝╧╍┼─╜						
		X:2	X:1 3 1					
5		• <u> </u>					γ.	-0 34
	R22 Short Circuit							
Ц	THE GROUP GROUP	(: 36	1				Z X:	აა —ი —
		1	1X				9 X:	32
					1		X:	31
*				MOC	12		Х:	
					, .X		⊥ ¥¥∕	
Н					1		А.	
				lield	11		₹	-0
		•		Sh	9 X::		X:	27
 ^				SL2	1		_м Х:	26
	0	1 4		B	14		<u> </u>	25
Н					2 X:1		ý.	-024
		3/4 3/4			1		L Q A	
							Y:	23
[~]				10	9 0			~
					5 X 1	L12		
Н						A A		
						2B 2B		
						3/1 3/1		
-				۔ ت				-
				3/41			TOTAL SHIFFTS 7	NO. OF SHFFTS 4
	र ा	~				i.	15	
	*		, ,	1	1	4		



Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual





Air Source Screw Water Chiller Unit – Installation Operation and Maintenance Manual





¥		β			ç			6	2			ŝ			r.			9			н		
																							12
-		nsor	.ve	ch	lucer	PLC	of PLC	ule of PLC	.e of PLC	Module of PLC	sen	Valve Module		xpansion Valve	ion Valve								μ
	DESCRIPTIO	Temperature Se	Solenoid Val	Pressure Swit	Pressure Transo	CPU Module of	Extended Adaptor	Extended Output Mod	Temperature Modul	Analog Singles Mixed	Touch Scre	Electrical Expansion	Switch Power	Power of Electrical E	Electrical Expans								10
	LEM		X		d																		9
	1C IC	22	6	SP3																			8
	I TEM SYMBO	20 RT1 [~] RT NTC	21 W1~YV	22 SP1 SP2	23 TP1 TP	24 A1	25 A2	26 A3	27 A6	28 A7	29 HMI	30 A8	31 A9	32 A10	33 EX1	34	35						7
	NOILT	ransformer	Circuit Breaker	Switch	Lamp	sction Module	r Contactor	verload Relay	otor	: Relay	ontactor	ency Stop	Transformer	sor Heater	low Switch	eze Switch	liate Relay	on Switch	e Switch	el Switch			6
	DESCH	Current 1	Moulded Case (Air		Power Prote	Compresso	Thermal 0	N	Time	Fan C	Emerg	Isolation	Compres	Water F	Anti-Fre	Intermed	Protecti	C/H Mod	0il Lev			5
	ITEM	W	 X Y Y	×			 p	_7_	(a) (Min)		 	077	m		∲	7.	-[]-		\1 				4
	SYMBOL	TA1 TA2	1QF	F1 QF2 QF3 QF4	HL1 HL2 HL3	KR1	KM11 KM12 KM13	FR FR1~FR10	M	KT1	KM1~KM10	SB	T1	EH1 EH2	SQ1	SQ2	KA1-KA7	SQ3	SA1	SL1			٤
	ITEM	1	5	n	4	2	9	7	∞	6	10	11	12	13	14	15	16	17	18	19			2
																	Γ	TOTAL	SHEETS 7	,	NO. OF SHEETS	7	1
ـــــــــــــــــــــــــــــــــــــ		90		1	Ç.			<i>c</i>	<u> </u>			40			4			6			Ŧ		

Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual



Wiring diagram for MRH380A-B3Z





Wiring diagram for MRH500A-B3Z





Wiring diagram for MRH600A-B3Z



7 Commissioning

7.1 Check Before Commissioning

7.1.1 Water System

- Ensure that all pipelines in the water system are clean and that the pipeline connection and water flow direction are correct.
- Check that the outlet and inlet pipes are in proper connection.
- Start the water valve.
- Start the water pump.
- Check whether water is leaked in pipes and joints.
- Start the discharge valve to discharge the air in the water system, and then stop the discharge valve.
- Detect the loss due to resistance on the cooling water side and check whether the water flow is correct.
- Check whether the inlet and outlet water temperature shown on the control cabinet is consistent with that shown on the thermometer.

7.1.2 Circuits

- Cut off the main power supply, and check each startup and control circuit in the power distribution cabinet. Check whether each component is installed securely and whether each wiring is connected correctly.
- Check whether the power supply of the unit is consistent with that shown on the nameplate. The maximum allowed unbalance between the output voltage and the rated voltage is 10%. The maximum allowed unbalance between phase voltages is 2%. The phase sequence of the power supply must be consistent with that shown on the unit.
- Check whether the power supply capacity is sufficient for the unit startup and full-load operation.
- Check whether the unit is connected to the ground.
- Ensure that all wires and fuses have proper specifications for unit operation. Complete the setting of all interlocking control lines and DIP switches according to the related electric control drawing.
- Ensure that all auxiliary and control devices run properly.

7.1.3 Unit

- Check whether the pressure and oil level inside the unit are normal.
- Check whether all safety control devices are in original states and whether the settings are correct.
- Check whether the valve of the unit is in correct position and whether you can hear fluorine leakage voice.
- Check whether the coil winding resistances (including the phase resistance, phase-to-phase

resistance, and resistance to ground) of the compressor are normal.

- Cut off the power supply of the compressor and then turn on the main power supply.
- Start the unit and check whether the switch between the star and delta AC contactors is normal (that is, check the voltage between the three contacts is 380 V). (Because the power supply of the compressor is cut off, the compressor is not powered on.)
- Check whether there is an open phase (the voltage to the ground of each phase should be 220 V).
- Check whether the onsite settings on the touchscreen conform to the requirements.
- Check whether the expansion valve can be turned on or off properly (control the expansion valve manually and check whether the step motor runs with normal operation voice).
- Check whether the load/unload solenoid valve works properly by performing manual load/unload.
- Check whether the oil heater of the compressor is in normal state and whether oil heating conditions are met.
- If all preceding items are normal, start the auxiliary devices and chilled water pump.
- Cut off the main power supply and turn on the power supply of the compressor.
- Turn on the main power supply again to start the unit.

7.2 Commissioning Operations

Àidea[®]

- Install a fluorine pressure gauge and a thermometer sensing probe on the unit and start the compressor. Check whether the star and delta AC contactors are started and switched properly. Check the voltage of the wiring at the bottom of each contactor.
- Check the current of the compressor.
- Check whether the fan runs properly and rotates in the correct direction. Then detect the operation current.
- Check whether the oil level is normal and whether the energy adjusting solenoid valve on the compressor operates properly. (You can use a nonmagnetic blade to check whether the valve has magnetism.)
- Let the compressor run more than 20 minutes. During this process, check and monitor all operation parameters, and observe the suction/discharge pressure of the unit.
- Through the return air superheat, check whether the opening of the electronic expansion valve is in a reasonable range.
- After the unit enters working conditions, check whether the return air superheat of the unit is within the range of 5–7. Check whether the discharge superheat and condensation subcooling are normal.
- When the discharge temperature is high, check whether the solenoid valve and expansion valve on the sparge pipe work properly. (You can use a nonmagnetic blade to check whether the valve has magnetism.)
- Stop the unit and check whether the oil level of the compressor is normal.
- To ensure that the unit can run all the time, start all terminal devices to provide sufficient air conditioning load.
- After the commissioning is complete, tighten all valve caps, clean the unit, and remove oil marks at all joints of fluorine systems.

8 Daily Use of the Unit

8.1 Check Before Use

- (1) Judge whether the time for heating up the refrigerator oil of the compressor is long enough. When you initially start the unit after it is powered off, the refrigerator oil must be preheated for 24 hours. In other cases, 4 to 8 hours is usually required. The oil temperature must be kept above 23℃. (The time for heating up the refrigerator oil of the compressor varies with the ambient temperature. The lower the ambient temperature is, the more time it requires.) You can obtain the specific heating time from the state information on the touchscreen.
- (2) Check whether the water flow meets the unit requirement.
- (3) Check whether all control switches and components in the power distribution cabinet are normal.
- (4) Check whether the power supply and voltage are normal.
- (5) Check whether the pressure gauge of the chiller is normal. In normal cases, when the outdoor temperature is 25℃–28℃, the pressure shown on the pressure gauge is 7–10 kgf/cm².

8.2 Unit Startup Sequence

- (1) Start the water pump of the water circulating system.
- (2) Start the compressor.
- (3) Start the fan motor (based on the discharge pressure of the compressor).

8.3 Unit Stop Sequence

- (1) Stop the compressor.
- (2) Stop the fan motor (based on the discharge pressure of the compressor).
- (3) Stop the water pump of the water circulating system.

8.4 Control Interface Structure



8.5 Operation

Notes:

- (1) The touchscreen displays the time of each event. Except programmable logic controller (PLC) events, the time of other events is consistent with that shown on the touchscreen.
- (2) It is prohibited to disassemble the display or add a communication wire for remote control. If you do this, the unit may be faulty due to signal interference. Our company will not take any responsibility for any hurt or consequence arising therefrom. If you really require remote control, you can customize the function from our company.
- (3) Be cautious to choose a switch for remote control. Only a point-moving type switch can be chosen. If you choose another type switch, the unit may automatically restart after being powered off. Our company will not take any responsibility for any hurt or consequence arising therefrom. When choosing a switch in remote control mode, you must choose a maintained switch. Otherwise, the unit is likely to work in only one state.
- (4) Three indicators (white, green, and red) are installed on the operating panel of the indoor control cabinet. The white indicator is the power indicator of the unit. If the unit is powered on, the white indicator turns on. The green indicator is the running indicator of the unit. If the unit is operating properly, the green indicator turns on. The red indicator is the alarm indicator of the unit. If the unit generates an alarm, the red indicator turns on.

Note: The following figure shows the home page screen of a single unit. If multiple units are in parallel connection, the input/output screen of each unit is displayed. The operation is the same as that performed for a single unit. The screen shown in the following figure is subject to change without notice. The actual screen shall prevail.

After being powered on, the touchscreen automatically enters the home page.



HMI program's version number

The indicators on the right of the panel are described as follows:

- (1) The yellow indicator is the power indicator. It keeps steady on in normal conditions. If it is off, check whether the power cable is connected correctly.
- (2) The green indicator is the running indicator of the touchscreen. It blinks at a low frequency in normal conditions.
- (3) The red indicator is the communication indicator. It blinks at a high frequency in normal conditions. If it is in other states, check whether the communication cable of the controller is correctly and securely connected to the panel.

After the system initialization is complete, click **ENTER**. The keypad is displayed, prompting you to enter the password, as shown in the following figure.





On the keypad, enter **58806** and click **Enter** to enter the mode setting page.



On this page, set a control mode and a running mode. The system's current control and running modes are displayed in the upper part of the screen.

Notes:

- (1) If the system is running, you can only change the control mode. Other modes cannot be changed.
- (2) The control mode is used to select a startup/shutdown mode for the unit. When the control mode is set to LOCAL, you can start or stop the unit by clicking the START or STOP button. When the control mode is set to REMOTE, you can start or stop the unit only through the REMOTE START or REMOTE STOP hardware interface. When the control mode is set to TIMED, you can start or stop the unit by setting a startup or shutdown time.

After setting the control mode, click **PgDn** to enter the next page (that is, the main page), or click **BACK** to return to the previous page (that is, the home page).



The main page displays unit information such as the current status, control mode, and running status. After you click **BACK**, the system returns to the mode setting page.

The unit's current status includes the following:

- 1. STANDBY: indicates that all output status of the unit is OFF, and the unit has been stopped.
- 2. STARTING UP: indicates that the unit is running based on the startup logic. If the compressor does not meet the startup condition, this status will be displayed all the time until the startup process ends.
- 3. RUNNING: indicates that the unit is running properly. In water pump mode, it indicates the running status of the water pump.
- 4. STOP: indicates that the unit is operating based on the power-off logic.



- 5. PAUSE: indicates that the energy adjustment device is standby and waits for temperature recovery. After the temperature is recovered, the compressor starts automatically.
- 6. FAULT: indicates that the unit is encountering a fault. After the fault is rectified, the status disappears.

On the main page, click **SETTING** to enter the password entering page.



On the displayed keypad, enter **40828**, and click **Enter**. The dialog box disappears. Click **Confirm** to enter the parameter setting page.

	SETTING						
Te	mp. Control Range	0.0	C				
Te	emp. Adjustment Perio	d	0	S			
C	ooling Setting Temp.(I	0.0	C				
Τe	emp./Cooling Compres	0.0	Ĉ				
	Clock Setting	Setting					
	Screen Setting Automatic O						
				BACK			

On this page, you can set the following items:

Temperature control range, temperature control period, control target temperature, and compressor startup temperature.

Notes:

- (1) On the password entering page, you can set an upper limit in the Max text box, and a lower limit in the Min text box. Click Enter to confirm your input or press Esc to cancel your input. The keypad then disappears.
- (2) The Automatic ON/OFF button is available only in timed mode.

Parameters displayed on the above page are described as follows:

Cooling Setting Temp.(LWT): indicates the target water temperature.

Tem./Cooling Compressor Start (LWT): indicates the (outlet water) temperature at which the unit can start the compressor. In case of cooling, the compressor can start only when the (outlet water) temperature is higher than the compressor startup temperature.

Temp. Adjustment Period: indicates the load/unload judgment cycle. If it is set to 60 seconds, the system judges the unit temperature once every 60 seconds, and checks whether load/unload is required. If yes, the system executes the load/unload immediately. In another 60 seconds, the system performs a judgment again. The cycle is repeated in such way.

Click Clock Setting to enter the time setting page.



On the user parameter setting page, click **Clock Setting** to set the time and date of the PLC and touchscreen. Note that you must click **Confirm** within 1 minute after you enter the time. **During this** process, you must set a valid date and time. If you set an invalid date and time, our company will not take any responsibility for any consequence arising therefrom.

Click Screen Setting to enter the touchscreen setting page.

	SCREEN SETTING	
Brightness	0 - +	
Contrast	0 - +	
Keypad Tone	OFF ON	
Backlight	10 M	
	BA	СК

On this page, you can click + or – to increase or decrease the brightness and contrast of the touchscreen. You can also click **ON** or **OFF** to unmute or mute the keypad tone of the touchscreen.

Click the text box in the **Backlight** field. You can then modify the time of the backlight.

Click **Comm. Setting** to enter the multi-connection setting page.

COMBINATION MODE				
Singe-U	nit	Read serial port information		
			BACK	

When multiple units need combination control, contact sales engineers or after-sale service engineers of

company to perform relevant settings for these units.

After the setting is complete, click Single unit. It then turns to Multi units, indicating that the units

are in the combination control state.



Then at the bottom of the screen, set the number of units that need combination control.

You can click **Read serial port information** to read serial port information when you set multiple units or set the host computer.

Read serial por	t information	
Baud rate	0	
Address:	0	
Data bit	0	
Stop bit	0	
Check bit	zero	
Interface	RS232	
		BACK

The Automatic ON/OFF button is available only when CONTROL MODE is set to TIMED on the mode

2012-05-3	30 (WED) 17	7:33:08		
	Starting time	Shutdown time		
SUN.	0:0	0:0	Invalid	
MON.	0:0	0:0	Invalid	
TUE.	0:0	0:0	Invalid	
WED.	0:0	0:0	Invalid	
THU.	0:0	0:0	Invalid	
FRI.	0:0	0:0	Invalid	
SAT.	0:0	0:0	Invalid	BACK

setting page. Click this button to enter the starting/shutdown time setting page.

Starting/shutdown time settings take effect only when CONTROL MODE is set to TIMED.

On the above page, you can set the starting and shutdown time of the unit on each day of a week. The unit starts and shuts down based on the settings. If the unit needs to run for more than one day, for example, from 10:00 on Tuesday to 16:00 on Thursday, you can perform the following settings:

- 1. Set the starting and shutdown time on Tuesday to 10:00 and 00:00 respectively, and click the Invalid button to validate the settings.
- 2. Keep the starting and shutdown settings on Wednesday invalid.
- 3. Set the starting and shutdown time on Thursday to 00:00 and 16:00 respectively, and click the Invalid button to validate the settings.

The timed starting and shutdown adopt the PLC's internal time. Therefore, if the unit is always powered off, you must check whether the PLC time is ever reset and whether the PLC battery has power when you use this function. If the PLC battery has no power, replace it.

On the main page, click **ALARM** to view alarm information of the unit.





On this page, you can click or to view a maximum of 100 historical alarm messages of the unit.



Notes:

- (1) The high pressure switch cannot be reset automatically. You need to find this switch on the unit to reset it manually.
- (2) The compressor and fan overload protection switches cannot be reset automatically. You need to find the thermal relay in the power control cabinet to reset the two switches manually.
- (3) After a PLC module fault is rectified, you must power off and then power on the unit to clear the fault.

On the above page, click **History Alarm Information** to enter the page shown in the following figure. You can then view the information about the five latest alarms, such as the temperature and pressure.



BACK		0 / 0	00/	00 SUN	. 00:00:00		
Warning Message							
Recently Zer	o Alarm	1	Α	larm Time			
UP	OWN	0	/	00/00 00	00:00		
AI		DI		DO	Unit 1		
LWT	0.0°C	Remote Start	OFF	Compressor	er Economizer er		
EWT	0.0°C	Remote Stop	OFF	Pump	🕶 Mid. Inject. 🛛 🔤		
Ambient Temp.	0.0°C	Water Switch	OFF	25%SOL. Val	. 🕶 Tail Inject. 🛛 🔤		
1#Discharge Temp.	0.0°C	High Pres. Switch	OFF	50%SOL. Val	. 🚾 Oil Supply Val. 🕶		
1# Suction Pres.	0.00Bar	Low Pres. Switch	OFF	75%SOL. Val	. 🚾 Cooling 🛛 🔤		
1#Discharge Pres.	0.00Bar	Power Prot. Switch	OFF	Fan NO.1	🔤 Alarm 🔤		
		Oil Level Switch	OFF	Fan NO.2	OFF		
		Anti-freeze Switch	OFF	Fan NO.3	OFF		
	Motor Prot. Switch 🔐 Fan NO.4 🔐						
Comp. Overload Prot.	Comp. Overload Prot. Switch 🐖 Contactor Protection 🐖 Fan NO.5 🐖 Unit 2						
Fan Overload Prot. S	witch 🚾			Fan NO.6	OFF CONTRACT		

Click Multi-status

l on the main page to enter the combination mode query page.

Note: The **Multi-status** button is available only when **COMBINSTION MODE** is set to **MULTI-UNIT** on the user parameter setting page.





2011/09/14 (WED) 17:13:17	
Please choose the module to query	
Unit NO.0	
Scan All	
	BACK

On this page, you can select a module to view its status or monitor the master unit to view the status of each unit.

To do so, click **Scan All** to enter the page shown in the following figure.

2011/09/14	(WED)	17:14:1	5			
	Comn	nunication	Alarm	Statu	ıs R	efrigerant
0#(Master)			Normal	Stop		R134a
					PgDn	BACK

Click $\ensuremath{\textbf{PgDn}}$ to enter the page shown in the following figure.

2011/12/05	(MON) 13	:42:44			
0#(Master)	Finish Oil Heating NO	Restart Delay NO	Min. running time NO	LWT too Low NO	Debug YES
				PgUp	номе

Click **Unit NO.0** on the combination mode query page, or **STATUS** on the main page when a single unit is connected to enter the page shown in the following figure.

R134a			
Pump Running	0 H Comp. Runn	ning	0 H
Remaining Oil Heating	0 M		
Restart Delaying		NO	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
Min. Running Time I	Elapsed	NO	
Alarm		NO	
Water Temp. Allow	Compressor Start	NO	
Load State		0%	
PLC Remaining Bat	tery Volume	0%	PgDn
			BACK

On this page, you can view the following information:

- Type of the refrigerant used in the unit, running time of the compressor and pump, and remaining time for heating up the oil in the compressor.
- Whether the unit generates an alarm, whether the compressor startup temperature is met, and whether the compressor startup failure is caused by insufficient restart delay.
- Whether the compressor unload failure is caused because the shortest running time of the unit is not reached.
- Unit running status (25%, 50%, 75%, or 100%)
- Residual electricity of the PLC battery

Notes:

To start the unit, ensure that the following conditions are met:

- (1) **Restart Delaying** must be set to **NO**. If it is set to **YES**, the startup delay is not reached.
- (2) Water Temp. Allow Compressor Start must be set to YES. If it is set to NO, the current temperature does not meet the compressor startup condition.
- (3) **Remaining Oil Heating** must be set to **0**. If it is set to a value larger than 0, the oil of the unit is being heated.

To shut down the unit, ensure that the following condition is met:

Min. Running Time Elapsed must be set to YES. If it is set to NO, the shutdown delay is not reached.

Click **PgDn** to enter the page shown in the following figure.

Discharge Temp.	0.0 °C	
Ambient Temp.	0.0 °C	
EWT	0.0 °C	
LWT	0.0 °C	
Suction Pres.	0.00 Bar	
Discharge Pres.	0.00 Bar	Pg
		Pg
		B

On this page, you can view the unit's temperature and pressure.

Click **PgDn** to enter the page shown in the following figure.

	001	PUT		1
Compressor	OFF	Reserved	OFF	
Pump	OFF	Economizer	OFF	
25%SOL. Val.	OFF	Mid. Inject.	OFF	
50%SOL. Val.	OFF	Tail Inject.	OFF	
75%SOL. Val.	OFF	Oil Supply Val.	OFF	
Fan NO.1	OFF	Bypass SOL. Val.	OFF	
Fan NO.2	OFF	Reserved	OFF	Palln
Fan NO.3	OFF	Reserved	OFF	Tgop
Fan NO.4	OFF	Reserved	OFF	PgDn
Fan NO.5	OFF	Cooling	OFF	
Fan NO.6	OFF	Alarm	OFF	BACK

This page displays the output status of the unit. **OFF** indicates that a point has no output. **ON** indicates that a point has output.

Click **PgDn** to enter the page shown in the following figure.

-	INPUT		
Remote Start Remote Stop Water Switch High Pres. Switch Low Pres. Switch Power Prot. Switch Oil Level Switch	 Comp. Overload Prot. Switch Fan Overload Prot. Switch Anti-freeze Switch Oil Pres. Differ. Prot. Switch Motor Prot. Switch Contactor Protection Reserved 	OFF OFF OFF OFF OFF	
EXV Feedback	OFF		PgUp
			BACK

This page displays the input status of the unit. **OFF** indicates that a point has no input. **ON** indicates that a point has input.

Notes:

- (1) **Remote Start/Remote Stop:** takes effect in remote control mode.
- (2) When there is no water flow, **Water Switch** is set to **OFF**. Otherwise, it is set to **ON**.
- (3) After contactors work properly during the compressor operation, **Contactor Protection** is switched from **OFF** to **ON**.

9.6 Fault Alarm Function

Fault	System's Determination	System's	Possible Causes	Rectifying Way
	Criteria	Handling Method		
Water flow failure	After the water pump	Stop the unit.	The water flow is too small.	Manual
	runs for 3 minutes, the		The water flow switch is	
	water flow switch trips		inserted in a wrong position.	
	out for 5 seconds.		The water flow switch is	
			inserted in a shallow position.	
			The water flow switch is faulty.	
			The wiring is loose.	
Anti-freeze	The anti-freeze	Stop the unit.	The water temperature is lower	Manual
protection	protection switch trips		than 3℃.	
	out for 3 seconds.		The anti-freeze switch is faulty.	
			The wiring is loose.	
High pressure	The high pressure switch	Stop the unit.	The discharge pressure of the	Manual
alarm	trips out for 3 seconds.		unit is too high.	
			The high pressure switch is	
			faulty.	
			The wiring is loose.	
Low pressure	The low pressure switch	Stop the unit.	The suction pressure of the	Manual
alarm	trips out for 1 second.		unit is too low.	
			The low pressure switch is	
			faulty.	
			The wiring is loose.	
Compressor	The compressor interior	Stop the unit.	The motor temperature is too	Manual
interior protection	protection switch trips		high.	
alarm	out for 3 seconds.		The motor runs reversely.	
			The power supply has an open	
			phase.	
			The three-phase voltage is	
			unbalanced.	
			The compressor interior	
			protection switch is faulty.	
			The wiring is loose.	

Air Source Screw Water Chiller Unit – Installation Operation and Maintenance Manual

Low oil level	The oil level switch trips	Stop the unit.	The oil level of the compressor	Manual
protection	out for 60 seconds.		is too low.	
			The oil level switch is faulty.	
			The wiring is loose.	
Oil pressure	After the unit starts	Stop the unit.	The oil filter is blocked.	Manual
difference	running, the oil pressure		The oil pressure switch is	
protection	difference protection		faulty.	
	switch trips out for 30		The wiring is loose.	
	seconds.			
Compressor	The compressor's	Stop the unit.	The compressor is overloaded.	Manual
overload	thermal overload relay		The thermal overload relay's	
	trips out for 3 seconds.		switch is faulty.	
			The wiring is loose.	
Fan overload	The fan's thermal	Stop the unit.	The fan is overloaded.	Manual
	overload relay trips out		The thermal overload relay's	
	for 3 seconds.		switch is faulty.	
			The wiring is loose.	
Power supply	The power protection	Stop the unit.	The three-phase voltage power	Manual
failure	module trips out for 3		supply is unbalanced.	
	seconds.		The voltage is too low.	
			The voltage is too high.	
			The phase is reversed or lost.	
			The power protection module	
			is faulty.	
			The wiring is loose.	
Contactor	After the compressor	Stop the unit.	The absorption of the contactor	Manual
protection	runs for 10 seconds, the		is unstable.	
	contact feedback		The control wire of the	
	protection switch trips		contactor is loose.	
	out for 0.1 second.		The absorption of the middle	
			relay before the contactor is	
			unstable.	
			The normally closed contacts	
			of the thermal relay are	
			unstable, or the thermal relay	
			trips out incompletely.	
High temperature	The discharge air	Stop the unit.		Manual
of discharge air	temperature keeps being			
	higher than 110℃ for 10			
	seconds.			
Open circuit of	The PT100's resistance	Stop the unit.		Manual
outlet water	is greater than 300 Ω .			
temperature				
sensor				

Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

Short circuit of	The PT100's resistance	Stop the unit.	Manual
outlet water	is smaller than 20 Ω .		
temperature			
sensor			
Open circuit of	The PT100's resistance	Stop the unit.	Manual
inlet water	is greater than 300 Ω .		
temperature			
sensor			
Short circuit of	The PT100's resistance	Stop the unit.	Manual
inlet water	is smaller than 20 Ω .		
temperature			
sensor			
Open circuit of	The PT100's resistance	Stop the unit.	Manual
ambient	is greater than 300 Ω .		
temperature			
sensor			
Short circuit of	The PT100's resistance	Stop the unit.	Manual
ambient	is smaller than 20 Ω .		
temperature			
sensor			
Open circuit of	The PT100's resistance	Stop the unit.	Manual
discharge	is greater than 300 Ω .		
temperature			
sensor			
Short circuit of	The PT100's resistance	Stop the unit.	Manual
discharge	is smaller than 20 Ω .		
temperature			
sensor			

8.7 Safety Protection Flowchart

8.7.1 Water Flow Failure





8.7.2 Freeze Protection



8.7.3 High Pressure Protection



8.7.4 Low Pressure Protection



8.7.5 Compressor Internal Protection



8.7.6 Low Oil Level Protection



8.7.7 Oil Pressure Difference Protection



8.7.8 Compressor Overload Protection



8.7.9 Fan Overload Protection



8.7.10 Power Supply Failure



8.7.11Contactor Feedback Protection





8.7.12 High Temperature of Discharge Air



8.7.13 Short Circuit of the Outlet Water, Inlet Water, Ambient, or Discharge Temperature Sensor



8.7.14 Open Circuit of the Outlet Water, Inlet Water, Ambient, or Discharge Temperature Sensor



8.8 Precautions for Unit Operation

WARNING

To prevent personal injury or death due to contact with any moving or live part, cut off the master power supply before check or maintenance, and suspend a sign "switch-on prohibited" near the switch.

- (1) Before initially starting the unit, ensure that it is powered on for more than 8 hours, in order to prevent foam phenomenon of refrigerator oil when the unit starts up. If the unit starts up in low temperature, the oil is very viscous, and the compressor is difficult to start and load. In this case, the oil must be preheated for more than 8 hours. When the system stops, the refrigerator oil heater continues to work. Do not cut off the power supply, because the refrigerator oil heater keeps on working after the system stops. When the unit is not in use for a long time, you can cut off the power supply.
- (2) Do not mix refrigerator oil of different brands. Confirm the brand specifications of the refrigerator oil when adding it. If you want to change the refrigerator oil, clean away all the remaining refrigerator oil inside the compressor and that in the system before adding new refrigerator oil and changing the drier-filter. Qualitative change may happen when some synthetic oil mixes up with mineral oil. Therefore, after adding the new refrigerator oil, change the new refrigerator oil to remove all the remaining oil after the unit starts up again.
- (3) If an accident occurs during compressor startup, you can click the **Emergency Stop** button on the touchscreen to stop the compressor.
- (4) Without the permission of company 's after-sale personnel, it is prohibited to change parameters of the electrical expansion valve. Otherwise, the unit may fail to run properly.
- (5) If the safety value of the store liquid organ is open, ensure that the ambient environment of the unit is well ventilated. When Freon meets fire, harmful phosgene will be generated. Therefore, do not light open fire around the unit.

9. Troubleshooting

Symptom	Cause	Solution	
	No power supply (or power interruption)	Power on after examination.	
		Identify the cause for over current. If the	
		contact capacity is too small, replace the	
	On-off action (over current)	contact capacity promptly. If the voltage is	
A. Compressor		too low, improve the voltage.	
breakdown	Starting switch failure	Repair or replace the switch.	
	Fuse that controls the loop melted	Replace the fuse.	
	Operation failure of interlocked	Check that the interlocked water pump	
	parts	operates properly.	
	High-low pressure switch action	Check the set voltage and adjust it if needed.	
		The ambient temperature is too high.	
		Vent the incondensable gas in the system.	
B. Power-off shortly	High-low pressure switch action		
after startup	rightion pressure switch deteri	Clean the expansion valve if blocked or	
		replace it if damaged.	
		Wipe the dusty finned heat exchanger.	
	Insufficient refrigerant	Chase leaks and recharge refrigerants.	
C. Too low exhaust	High superheat of the expansion valve	Adjust the superheat.	
pressure	Too low ambient temperature	Check the ambient temperature and close	
		certain fans if necessary.	
	Too low suction pressure	See "F. Too low suction pressure."	
	Excessive refrigerants	Suck a moderate amount of refrigerants.	
	Mingled with incondensable gas	Vent the incondensable gas.	
	Dirty finned heat exchanger	Clean the finned heat exchanger.	
	High temperature in the finned heat	Check the ambient temperature and the	
D. Too high exhaust	exchanger	surroundings of the finned heat exchanger	
pressure		to ensure unimpeded air intake.	
	Insufficient air volume of the finned heat exchanger	Check the running status of the fans.	
	Imprecise high voltage meter	Replace the high voltage meter.	
	Too high suction pressure	See "E. Too high suction pressure."	
E. Too high suction pressure	Over refrigeration load	Adjust the refrigeration load and water	
		circuit.	
	Low superheat of the expansion valve	Adjust the superheat.	
	Insufficient refrigerant	Chase leaks and recharge refrigerants.	
F. Too low suction	Blocked drier-filter	Clean or replace the drier-filter.	
pressure	Less refrigeration load	Adjust the refrigeration load.	
	Insufficient chilled water	Adjust the chilled water volume.	
Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

Symptom	Cause	Solution				
	Blocked chilled water filter	Clean the chilled water filter.				
G Malfunction of the	Temperature regulator failure	Replace the temperature regulator.				
	Solenoid valve wire cut	Replace the wire of the solenoid valve.				
	Blocked capillary tube	Clean the capillary tube (by a				
		professional).				
	Defective bearing	Upgrade the compressor.				
	Too high pressure on the high	See "D. Too high exhaust pressure "				
H Overheated	pressure side					
compressor	Refrigerants with too high pressure	Adjust the pressure on the low pressure				
	and temperature on the low	side and the opening of the expansion				
	pressure side	valve.				
	Overheated motor	See "E. Too high suction pressure."				
	Short-circuit between distribution	Measure the insulation resistance value.				
	cables					
I. NFB tripping	Signal earthing	Measure the insulation resistance value.				
		Measure the motor insulation resistance				
	Motor failure	against ground and phase-to-phase				
		insulation resistance.				
	Single phasing due to NFB tripping	Check the NFB.				
	loo high, too low, or unbalanced	Check the power distribution status of the				
		motor.				
	Single phasing due to the defective	Repair or replace the electromagnetic				
	electromagnetic switch	Switch.				
	Defective meter	Repair or replace the motor. If the motor is				
J. Overload relay		burned, clean the reingerant circulation				
used by the		Keep the temperature below 60% in the				
	Too high temperature in the power	nower distribution box Identify and				
compressor	distribution box	eliminate the cause for overheat				
	Too high operating pressure	See "D. Too high exhaust pressure "				
		Check the respective automatic				
	Frequent startup of the compressor	adjustment structures				
	Insufficient refrigerant oil in					
	compressor	Clean the oil strainer.				
K. Concatenated	Telecommunication line cut	Check the telecommunication line.				
communication	Auxiliary engine power-off	Power on the auxiliary engine.				
tailure						

10 Maintenance and Service

WARNING

The water chiller unit must be maintained and serviced by experienced professionals.

CAUTION

Please print and fill in the sheets in appendixes 1 to 3 of this operation manual.

10.1 Normal Operating Pressure

The following figures show the low pressure and high pressure of the water chiller unit.

Low pressure: If the normal operating pressure of the shell-and-tube heat exchanger is lower than 1.5 bar, the water chiller unit is in abnormal status.

High pressure: If the exhaust pressure for normal operating is lower than 6.7 bar or higher than 20.5 bar, the water chiller unit is in abnormal status.

If the pressure is in abnormal status after the water chiller unit operates steadily, see "10. Troubleshooting."





10.2 Cleaning the Shell-and-Tube Heat

Exchanger Operation Procedure:



Stop the water chiller unit and the circulating water pump. Disconnect the water system of the shell-and-tube heat exchanger. Install one acid-proof water pump to form a water circuit as shown in Figure 5.1.

Figure 5.1 System connection diagram for clean water



- Add clean water to the sanitary tank and operate the acid-proof water pump. Check that the water pipe is tightly installed in good ventilation without water leakage between joints and without abnormal sound during the operation. Keep the devices around the water chiller unit away from rinse liquid.
- Drain water from the air conditioning system. Add the diluted rinse liquid in the sanitary tank to the water chiller unit using the acid-proof water pump. Circulate the diluted rinse liquid for a proper duration based on the type and concentration of the rinse liquid, and the thickness of dirt.
- Stop the acid-proof water pump. Release the liquid waste after cleaning to the waste water tank, and add clean water to the sanitary tank. Operate the water pump to clean the system with clean water. Use pH test paper to test hydrogen ion concentration. Add neutralizer gradually to the sanitary tank until the pH is 7. Keep the water pump running to circulate the water until neutralization is complete. Drain the water. Operate the circulating water pump to clean the system with clean water until no scale comes out.
- Release the clean water after cleaning to the waste water tank, and add neutralizer to neutralize the liquid waste. After the neutralization is complete, contact a professional liquid waste disposal company for processing.
- Reconnect the water pipes of the water chiller unit according to the operating status. Check relevant joints to ensure that the unit operates properly.

Precautions for Using Detergents:

- Wear rubber gloves when doing the cleaning work. Prevent detergents from spraying onto clothing, face, or coating surface. Rinse the detergent with clean water immediately in case of contact with it.
- Use a plastic or glass container rather than a lead one to keep detergents.
- For the used detergents, neutralize them with lime or soda, and then contact a professional liquid waste disposal company for processing.
- Preserve detergents beyond children's reach because the detergents are harmful.
- Operate the water chiller unit again after cleaning to verify the cleaning effect. If the intended result is not achieved, clean the unit once more.

10.3 Procedure for Replacing the Dry FilterElement

- Turn off the shutoff valves on both ends of the drier-filter (if the shutoff valve is available only on one end, recycle refrigerants).
- Vent a slight amount of refrigerants out of the drier-filter.
- Open end caps of the drier-filter.
- Replace the old dry filter element with a new one.
- Reinstall the end caps of the drier-filter (check whether the gasket is damaged during removal) and tighten the bolts.
- Evacuate certain sections of the drier-filter.
- Turn on the shutoff valves to make startup ready.

10.4 Lubricant

MLSC_A series air-source screw water chiller units have been charged with sufficient lubricant before

they leave the factory.

Model of the lubricant: BSE170

Viscosity: 170

If the water chiller unit in long-term use fails to start or stop upon the low oil level alarm, the causes will be:

- Lubricants have entered the refrigerant system and need to be recovered.
- Lubricant is undercharged and the following measures are required.

Measures:

- Keep the water chiller unit running at full load for one and a half hours. Check whether the oil level of the compressor rises.
- Restart the water chiller unit and ensure that it operates properly. If the oil level is still low, the lubricant
 in the unit is undercharged.

If the internal pressure of the compressor is 0 bar, charge lubricants for the compressor using its oil filler plug. If the internal pressure of the compressor is higher than 0 bar, charge lubricants for the compressor using an oil filling machine.

• Use the lubricant brand defined in the technical specifications when maintaining or charging lubricants.

10.5 Charging and Evacuating Refrigerants

Refrigerants have been charged in the MLSC_A series air-source screw water chiller units before the units leave the factory, and passed the units' performance test. This section describes how a professional from the service department charges refrigerants to a moderate level after replacing certain components of the units for maintenance.

Method of charging and evacuating refrigerants:

- 1. After evacuating the units, use the needle valves of the stop valves on both ends of the drier-filter to charge refrigerants.
- 2. Evacuate refrigerants from the needle valves of the stop valves.
- 3. Use a special refrigerant charging and evacuating device to charge refrigerants (R134a) to or evacuate refrigerants from the units.

Charge the R134a evacuated from the units into a fluid reservoir, which is designed to withstand the pressure of the units and comply with related standards of pressure vessels. It is forbidden to drain the R134a directly into air or sewers.

Determining the Amount of Refrigerants:

To check whether the refrigerant charge of the water chiller unit is insufficient, view the mirror on the supplying line and evaporation pressure by performing the following steps:

- Check that the unit operates at full load when the loop is running at full load. See the steps described in the control section.
- When the unit operates at full load, ensure that the outlet water temperature of the evaporator ranges from 5.5℃ to 6.5℃.
- View the mirror on the supplying line.

The refrigerant charge is appropriate if the mirror is clear without bubbles, the liquid lens of the compressor is at the full level, and the evaporation temperature is within the normal range.

However, the refrigerant charge is insufficient if bubbles appear at the bottom of the mirror and the evaporation temperature is below the normal range.

Maintenance Items		Maintenance	Acceptability Baseline	Bomorko
		Frequency	(Handling Method)	Remarks
	Noiso	Aputimo	Check whether an abnormal sound can be	View the
	NUISE	Anytime	heard.	items 1
A. Generality	Vibration	Anytime	Check whether the amplitude of vibration of auxiliary pipes and components is too high.	meter to the center of the water chiller unit.
	Voltage	Anytime	The voltage must be within ±10% of the rated voltage.	
	Stain	Anytime	Keep clean always.	
B. Unit	Duct	Apytimo	Use an iron brush to remove the rust and	
exterior	RUSI	Anyume	then apply anticorrosive paint.	
	Looseness	Anytime	Tighten screws.	

10.6 Routine Maintenance Items



Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

Maintonanao Itoma		Maintenance		Acceptability Baseline	Pomarka
		Frequency		(Handling Method)	Remarks
	Flake of insulation materials	Anytime		Use adhesives to paste the insulation materials.	
	Water leakage	Once per month		Check whether the sewer is blocked.	
	Noise	Anytime		Check whether an abnormal sound can be heard when starting, operating, or stopping the unit.	
	Insulation	Once	per	The insulation resistance must be over 5 $M\Omega$	
	resistance	year		when tested using a DC 500 V megger.	
C. Compressor	Aging of the shock absorption rubber	Once per year		Press the shock absorption rubber by hand. If the rubber is resilient, it is acceptable.	
	In-process	Once per		Pay attention to noise vibration and oil	
	inspection	3000 hours		level.	
	In-process inspection	Once per 6000 hours		Confirm the actions of safety and protection devices.	
D. Finned heat	Fan	Anytime		Air volume is normal and high pressure is within the normal range.	
exchanger	Cleanness	Once per month		Air resistance is normal and high pressure is within the normal range.	
	User-side water flow	Anytime		Between –5% and +5%	
	Temperature	Anytime		Within the benchmark range	
	Anti-icing fluid density	Once month	per	Over the set density	
E. Shell-and-tube	Water quality	Once month	per	Within the benchmark range	See appendix 4.
heat exchanger	Cleanness	Anytime		Ensure the low pressure is within the benchmark range during refrigeration.	
	Drainage	Anytime		Drain the water out of the shell-and-tube heat exchanger when the heat exchanger is not used for a long time.	Drain the water out of the auxiliary pipes too.



Air Source Screw Water Chiller Unit - Installation Operation and Maintenance Manual

Maintonanao Itoma		Maintenance	Acceptability Baseline	Domorko
	ems	Frequency	(Handling Method)	Remarks
F. High-low pressure switch	Action	Once per month	Check based on the action values of various protection devices.	Check whether the joint structures are in good condition during action.
G. Pressure	Pointer	Once every	Compare the pressure gauge with a	
gauge				
H. Stop valve	Action	month	Smoothly turn on or off the stop valves.	
I. Refrigeration cycle	Refrigerant leakage	Once per month	Check whether refrigerant leaks in the unit and joints of auxiliary pipes using a leak detector. Drain water out of the shell-and-tube heat exchanger. Check whether water leaks in the water inlet and outlet.	Use an electronic leak detector, a burner leak detector, or soapsuds.
	Insulation	Once per	The insulation resistance must be over 1 $\ensuremath{M\Omega}$	
	resistance	month	when tested using a DC 500 V megger.	
J. Electrical control	Wire contact performance	Once per month	Ensure that the insulation layer of the wire is intact in good contact and the bolts are tightened.	
	Auxiliary relay	Once per month	No abnormal action	
	Time limit relay	Once per month	Act based on the set time.	

10.7 Safety Requirements for Maintaining the Water Chiller Unit

 All installation components must be maintained by professionals to avoid damage to the water chiller unit and personal injury. The safety devices of the unit must be examined after each maintenance.

Once leakage is detected, vent all refrigerants out of the loop and repair leak sources. Then charge sufficient refrigerants based on the dose on the nameplate.

However, if refrigerants leak on isolatable components of the unit, you do not need to vent all refrigerants out of the loop.

Confirm the refrigerant model based on the nameplate before charging refrigerants. Charging

improper refrigerants will lead to unit failure or even compressor scrap.

- Use the lubricant brand defined in the technical specifications when maintaining or charging lubricants.
- Do not attempt to introduce oxygen to the supplying line of the unit because oxygen can react violently with oil.
- The operating pressure of the unit must not exceed the specified maximum working pressure.
- Use only refrigerants or dry nitrogen to chase leaks of the unit.
- Do not use electric soldering or flame to cut any refrigerant loops or components unless the unit contains no gas or liquid refrigerants.
- Refrigerants in contact with open fire will produce toxic gas. Appropriate measures must be taken to
 protect the unit and fire extinguishers must be accessible.
- Wear safety glasses to protect skin or eyes from refrigerants. Flush the refrigerants on skin immediately with soap or water if any. Flush the refrigerants in eyes with water immediately and repeatedly and seek medical attention.
- Use warm water rather than open fire or steam to heat the refrigerant container. Otherwise, the pressure may be too high, presenting potential hazards.
- Do not attempt to remove any end caps of joints when the unit is under certain pressure or in operation. Before performing operations on valves that may communicate with air after being opened, confirm that no pressure exists within the unit.
- When corrosion, foreign matter, dust, stain, or fouling is found within the valves, or the mechanical structure of the valves is damaged, replace the valves immediately instead of attempting to repair or respecify any safety devices.

Appendix 1

Daily Inspection Record Sheet

Data	Ambient	Inlet Water	Outlet Water	Exhaust Pressure	Suction Pressure	Exhaust	Suction
Date	Temperature (°C)	Temperature (℃)	Temperature (°C)	(bar)	(bar)	Temperature (℃)	Temperature (°C)
1							
2							
3							
4							
5							
6							
7							
8							
9							
10							
11							
12							
13							
14							
15							
16							
17							
18							
19							
20							
21							
22							
23							
24							
25							
26							
27							
28							
29							
30							
31							

Note: This sheet will be printed and filled by customers. Please keep it carefully.

Appendix 2

Key Component Inspection Record Sheet

Item	Comp	pressor		Water Excha	Side anger	Heat	Air Si	de Heat E	xchanger	Fan			Valve			Elect	ric Control	Cabinet	Othei	S	
Interval	Date	Inspector	Content	Date	Inspector	Content	Date	Inspector	Content	Date	Inspector	Content	Date	Inspector	Content	Date	Inspector	Content	Date	Inspector	Content
6 months																					
1 year																					
2 years																					
3 years																					
4 years																					
5 years																					
6 years																					
7 years																					
8 years																					
9 years																					
10 years																					
11 years																					
12 years																					
13 years																					
14 years																					
15 years																					

Notes:

- 1. Fill in A, B, or C in the content column. A: Normal B: Replace components C: Repair components
- 2. Key inspection points: (1) Color of the compressor oil (2) Differential oil pressure (3) Front and rear differential pressure of the drier-filter and color of the test paper of the liquid lens

Note: This sheet will be printed and filled by customers. Please keep it carefully.

Appendix 3

Maintenance (Repair) Record

S/N	Failure Description	Handling Measures	Handling Result	Recorder
1				
2				
3				
4				
5				
6				
7				

Note: Fill in the sheet and keep it carefully.

Relationship Between Water Quality and Scale/Corrosion

0.01				
S/N	Water Quality	Scale	Corrosion	Remarks
1	Acid water with a pH	Hard scale	Strong	The water can generate
_	lower than or equal to 6		ouong	CaSO ₄ easily.
	Alkali water with a pH			Iron ion or aluminum ion
2	higher than or	Soft scale		generates soft fluid
	equal to 8			precipitates.
~	Water rich in Ca2+ and			The water can generate
3	Mg ²⁺			hard scale easily.
4	Motor rich in Ol	Casla	Quite	The water can violently
4		Scale	strong	corrode copper and iron.
	Water rich in \mathbf{OO}^{2} and			The water can generate
5	water rich in SO_4^- and	Hard scale	Strong	hard CaSO ₄ and CaSiO ₂
	SIO ₂ ⁻		_	easily.
				The water can generate
6	Water rich in Fe ³⁺	Much hard	Strong	Fe(OH) ₃ and Fe ₂ O ₃
		scale	_	precipitates easily.
				The water can generate
			Quite	sulfide, ammonia,
1	Water with foreign odor	Much scale	strong	methane, and H_2S that
				corrodes copper strongly.
				The water can generate
8	Water containing	Much scale		hard scale easily.
	organic substances			
	Waste gas vented from			
	automobiles, chemical			Poor water quality can
	plants, electroplate		C	easily corrode and
9	plants, sewage plants,		Strong	puncture the copper pipe
	ammonia refrigeration			of the heat exchanger.
	plants, and fiber plants.			
	Powder from plastics			
	plants and other places			
10	that produce a large	Much scale		
	deal of powder			
<u> </u>	Sulfurous acid gas in		Quite	
11	the air		strong	